

Installation, Operation and Maintenance Instructions



METAL SEPARATOR CONTROL UNIT MODEL CF, CFP, & FF

ERIEZ MAGNETICS HEADQUARTERS: 2200 ASBURY ROAD, ERIE, PA 16506-1402 U.S.A.
WORLD AUTHORITY IN SEPARATION TECHNOLOGIES

Introduction

This manual details the proper steps for installing, operating and maintaining the Eriez Metal Separator Control.

Careful attention to these requirements will assure the most efficient and dependable performance of this equipment.

If there are any questions or comments about the manual, please call Eriez at 814-835-6000 for Metal Separator Control assistance.

 **CAUTION**

**Safety labels must be affixed to this product.
Should the safety label(s) be damaged, dislodged
or removed, contact Eriez for replacement.**

Table of Contents

ERIEZ METAL SEPARATOR CONTROL UNIT - MODELS CF, CFP, & FF

GENERAL INFORMATION.....	6
Introduction	6
Field of Application.....	6
Application Reasons	6
System Identification.....	6
Symbols Used.....	6
Overview	7
DESIGN AND METHOD OF OPERATION.....	7
Functional Principle.....	7
Functional and Control Elements.....	7
Operating Module with LCD Graphic Display	8
Cable Glands.....	8
Control IO Electronics Board	9
Control CU Electronics Board.....	10
DIMENSIONS AND TECHNICAL DATA	11
Environmental Conditions for Operation, Storage, and Transport	11
Noise Levels	11
SAFETY.....	12
Intended Use.....	12
Safety Signs.....	12
Dangers Arising from Non-Compliance with Safety Notes.....	12
Safety Information for Operators.....	13
Safety Information for Operation, Maintenance, and Cleaning	13
Safety Information for Commissioning	13
Safety Information for Storage and Transport.....	13
Notes on Residual Risks.....	13
Notes on Stable Standing Requirements.....	13
Consequences of Unauthorised Modification	13
Improper Use	13
COMMISSIONING.....	13
Mechanical Mounting	13
Connection of the Equipment.....	13

Table of Contents *(continued)*

ERIEZ METAL SEPARATOR CONTROL UNIT - MODELS CF, CFP, & FF

Control/IO Electronics Board (Control Electronics Board).....	14
Control/CU Electronics Board (Evaluation Electronics Board)	15
Electrical Performance	16
Drawing of Input/Output Connections.....	16
Electrical Connection of the Equipment.....	16
Mains Supply via Safety Socket.....	16
Mains Supply via Terminal Box	17
Behavior of Machine at Start Up.....	18
Relays - Operating Status	18
MENU/OPERATION	19
General Operation	19
Quick Start	19
Language Start.....	19
Menu Structure	20
Main Menu.....	20
Output Menu Items.....	20
Function Menu Items.....	20
Setting Menu Items.....	20
Setup Menu	21
Operating Mask	25
Change Product.....	26
Auto-Set.....	27
Product Parameter	28
Conveying Speed	28
Output.....	29
Output Adjust.....	29
Output Lock.....	30
Monitoring	30
Output Level.....	30
Output Options	31
Setup	31
Logbook	32
Clear Logbook.....	33
Show Counter	33
Device-Info	34
Revision	34
Change Password.....	35
Language	35
Clock/Date.....	35
Setup Options	36
Units	36
Frequency Deviation	36
Factory Settings	37
Login	37
Logout	37
Air Pressure Monitoring (Option).....	37
Flap Monitoring (Option)	38
External Error (Option).....	38
Ejection Monitoring (Option).....	38



Table of Contents *(continued)*

ERIEZ METAL SEPARATOR CONTROL UNIT - MODELS CF, CFP, & FF

ERRORS AND ERROR REMEDYING	39
Error Messages.....	39
Receiver Voltage Too High	39
Receiver Faulty.....	39
Transmitter Faulty.....	39
Transmitter Over Temperature.....	39
Hardware CU.....	39
Hardware IO	39
Communication IO.....	39
Watchdog.....	39
Memory Error.....	40
Short Circuit MV	40
Connection MV	40
Air Pressure.....	40
Diverter Position	40
Sensor 1 Faulty	40
Sensor 2 Faulty	40
Filling Level.....	40
Undefined Activation of the Switching Outputs	41
External Error	41
Replacing the Battery Backup.....	41
Replacement of Electronic Boards.....	42
Replacing the CU Electronics Board	42
Replacing the IO Electronics Board.....	42
Replacing the Display Board	42
MAINTENANCE AND CLEANING.....	43
Maintenance	43
Cleaning.....	43
Hints for Cleaning	43
Cleaning Instructions.....	43
Care Advice for Stainless Steel	43
Important Information for Stainless Steel Models.....	43
SPARE PARTS.....	44
Spare Parts View	44
Spare Parts List	45
SHIPPING, PRESERVATION, WASTE DISPOSAL, TRANSPORT, STORAGE.....	46
Shipping, Preservation, Waste Disposal.....	46
Transport.....	47
Storage	47

General Information

Introduction

The text and illustrations in this instruction manual are for the exclusive purpose of explaining how to operate and handle the control unit. The manufacturer accepts no responsibility for damage resulting from the use or misuse of this equipment. All appropriate safety rules and regulations for the use of this equipment must be adhered to. If you have any questions with regard to the installation and operation of this equipment please do not hesitate to contact us.

This instruction manual may not be copied, saved on computer or otherwise reproduced without the prior permission of the manufacturer. Nor may any extract of this instruction manual be similarly reproduced.

Field of Application

The control unit is used in combination with Eriez metal detectors and separators in the plastics, wood, food, chemical, and in a special version also in the pharmaceutical industry. Depending on the respective version, these systems inspect packed, unpacked, or piece products, and bulk materials for magnetic and non-magnetic metal contaminations. Of course they also are suitable for similar applications in other branches of industry.

Application Reasons

- Product liability
- ISO 9000
- TQM (Total Quality Management)
- Protection of machines and quality assurance

System Identification

The information in this instruction manual only applies to the CF, CFP, and FF control units. A label with the respective data is attached at every system.


Symbols Used

	Danger Possibility of severe or even fatal personal injuries.
	Danger Possibility of severe or even fatal personal injuries from electric current.
	Warning Possibility of minor personal injuries or property damage.
	Caution Possibility of defects or destruction of the equipment.
	Important Information Indicates important information about the function.
	Important Hint Indicates an important hint about the function.

Overview




Control Unit



Graphic Display

Design and Method of Operation

Functional Principle



The metal detector works with the so-called “balanced coil” principle:

The transmitter winding in the search coil creates a high-frequency electromagnetic field, which is received by symmetrical placed receiver windings. The windings are connected against each other; when undisturbed, the system is in balance.

An electrically conductible object within the detection area disrupts this balance and the electronic creates a switch signal. A “teach in process” allows to suppress the conductivity of the product itself. Deviations from the taught-in product are usually caused by metal contaminants, which are detected by the device with high precision.


The metal detector is equipped with comprehensive test and analysis software to ensure fault-free operation and retracing of product errors.

Interfaces allow simple operation as well as connection to a data management system.

! For reasons of the employed technology it is not possible to guarantee 100% metal detection.


Functional and Control Elements

Operating Module with LCD Graphic Display



1	Graphic Display	LCD module	Display of operating and input masks
2	Operator Keys	+ - ← Esc	For operating and machine settings
3	Function Key	Reset	Reset to restore the unit after metal or fault signal
4	Function Key	Test	Test function for metal detectors
5	Red LED	Metal	Illuminates when metal detected
6	Green/Red LED	Operating	Lights green in normal operating mode
		Fault	Lights red in case of fault and error


Cable Glands



- 7. Cable Gland for the Mains Cable
- 8. Cable Gland for Option
- 9. Cable Gland for Option
- 10. Cable Gland for Free Use
- 11. Cable Gland for Option
- 12. Cable Gland for Connecting the Detector Coil




Control / IO Electronics Board



Connectors and Terminals	(1) "Mains/Option" (2) "Relay metal" (3) "Relay fault" (4) "Switching outputs" (5) "Switching inputs" (12) "MV voltage external" (18) "CU connection"	L/N: Control unit power supply O1/O2: Optional 24V module power supply Potential free change over contact Potential free change over contact J5, connector, magnetic valves, signal combi., etc. J6, connector, sensors, switches, etc. J13, connector 24V external (option) J10, plug connection to CU electronics
Elements Connected to Mains Voltage	(1) "Connector, Mains/Option" (10) "Mains fuses"	
Elements Connected to External Voltage	(2) "Connector, relay metal" (3) "Connector, relay fault"	
Light Diodes	(7) "Monitor LED, MV1-3" (9) "Monitor LED, relay" (17) "Monitor LED, Vcc"	LD 10, magnetic valve (MV1) LD 9, magnetic valve (MV2) LD 8, magnetic valve (MV3) LD 11, relay fault (84, 81, 82) LD 12, relay metal (74, 71, 72) LD 1, +24V LD 2, +10V LD 3, +3.3V
Jumper	(6) "MV connection monitor" (11) "MV voltage supply" (15) "Service jumper"	JP10, 1-2, MV1 JP10, 3-4, MV2 JP10, 5-6, MV3 JP3, 2-1 external 24V (connector J13 +/-) JP3, 2-3 internal, 24V (default) J8, 5-6, plugged, enable, program update
Test Points	(8) "GND_24V" (16) "GND"	TP2, magnetic valves (MV1- MV3) TP1, IO electronics
Interface/Plug	(14) "Program update" (13) "Data backup"	J11, mini USB, (only for trained staff) JP9, USB selection (jumper plugged) J14, USB interface (system / product data) JP9, USB selection (jumper open)
Fuse	Description	Type
F1	Mains Supply	1.6A slow-blowing 1500A @ 250VAC 5x20mm

Control / CU Electronics Board



Connectors and Terminals	(1) "Receiver" (2) "Transmitter" (9) "Service interface" (11) "FFC connector" (12) "Memory"	J10, input signal from the detection coil J7, output signal to the detection coil J11, diagnostics interface J5, ribbon cable connector to the display module J4, system / product data
Test Points	(3) "Transmitter signal" (6) "GND"	TP7, sine signal (25V _{ss}) to the detection coil TP8, TP19, reference ground for all signals
Jumper	(8) "Service jumper"	J2, 5-6, plugged, enable, program update
Interface/Plug Connectors	(10) "Program update"	J9, mini USB, (only for trained staff) (JP2, observe jumper position)
Light Diodes	(5) "Monitor LED,s, Vcc" (4) "Monitor LED's"	LD 5, +24V LD 6, +5V LD 7, -5V LD 8, +15V LD 9, -15V LD 10, 3.3V LD 4, green, operating status LD 3, red, fault status
Memory	(12) "Memory devices" (7) "Battery"	J4, device and product data BT1, for real-time clock

Dimensions and Technical Data

Environmental Conditions for Operation, Storage, and Transport

The environment of the control unit should be free of any chemical vapours such as softeners, chlorine, or similar substances. The control unit must not be exposed to direct sunlight or to other environmental influences (rain, snow and storm). For ambient temperature conditions for operation, storage, and transport please refer to the technical data sheet in the annex.

Noise Levels

Sound pressure level measurements (in acc. with DIN 45 635)

Peak value of sound pressure level at a distance of 1m from the machine surface and 1.60m above the floor, LpA, 1m, max.

Result:

Idling: < 70 dB(A)
Activated: < 90 dB(A)

We reserve the right to change the contents due to product innovation or technical improvement.

Safety

Our equipment conforms to all official technical safety regulations. However, as a manufacturer we believe it is our duty to make you aware of the following information.

DANGER

The following safety and danger notes are intended for your protection, for the protection of third parties, and for the protection of the equipment. The safety notes therefore should always be observed!

Intended Use

 The equipment is intended for use in the following fields of application and only in combination with a corresponding detection coil of series CF, CFP, FF: Suction/pressure conveyor applications, free-fall applications, and applications at a conveyor belt. The equipment can be used in the plastics, food, animal feed, recycling, and chemical industry. Basically it is possible to also use the system in other applications than the intended use stated herein, but such applications always require the prior consultation and approval of Eriez.

Safety Signs

	Cover of the Electronics Housing	This symbol indicates that mains voltage is used in the electronics housing, and that any connected external circuits (e.g. at the metal relay) also may be energised. There is danger of electric shocks due to the presence of mains voltage. Connection symbols: "Mains" (1)  "Metal" (2) and "Fault" (3) 
---	----------------------------------	--

Dangers Arising from Non-Compliance with Safety Notes

DANGER

Any non-observance of safety notes constitutes a danger for life and health.

Safety Information for Operators

DANGER

The control unit may only be operated in the intended purpose and in a perfect functioning condition, especially the cover of the electronic housing has to be closed during operation. Entered moisture has to be removed! All fixed warning signs on the equipment may not be removed and have to be in a well recognizable condition. The operating instructions always have to be in a legible condition and complete available. Prior to commissioning always make sure that the applicable accident prevention regulations are observed. If the control unit is not mounted at the detection coil, it must be properly and firmly fastened by means of the four screws. The operator must make sure that the equipment is mounted at an ergonomic height for operation. The operator may only appoint qualified personnel for operation, maintenance and repair work. If potentially explosive materials are examined, the pertinent regulations must be observed.

DANGER

EMITTED INTERFERENCE

Test report according to the provisions of:
BGV B11:2001-06:

Regulations of the professional association for safety and health at work. Accident prevention regulations for electromagnetic fields.

E DIN VDE 0848-3-1: 05-2002:

Safety in electrical, magnetic, and electromagnetic fields, part 3-1: Protection of persons with active implants in the frequency range of 0Hz to 300 GHz. In the area where the operating personnel is working the electromagnetic field of the metal detector or separator does not exceed the limits stated in the provisions. Therefore there are no health impairments due to electromagnetic fields in this area for persons and for wearers of medical implants such as cardiac pacemakers. Inside the coil of round or closed tunnel coils, or on the surface of flat coils, the limits may be exceeded depending on design and system version. If work is to be performed inside or at the search coil, persons and wearers of medical implants such as cardiac pacemakers may only enter the equipment when it is turned off, provided that size and design allow this.

Safety Information for Operation, Maintenance, and Cleaning

DANGER

Because of energised components in the electronics housing there is a risk of injuries due to electric shock or burns. During operation the cover of the electronics housing must be kept closed. Only qualified personnel may operate and clean the equipment.

DANGER

If the electronics housing must be opened for maintenance or cleaning purposes, remove any dirt and moisture from the electronics housing, so that no larger amounts may get into the interior. Always disconnect the power supply and any connected external circuits before opening the cover. Any moisture that has penetrated into the interior must be removed from the electronics housing. If any maintenance work must be performed in energised condition, e.g. battery replacement, such work may only be performed by a qualified electrician under strict observation of the attached warning labels and with due regard to standard approved rules of electrical engineering.

DANGER

No safe condition is established when outputs are switched “inactive” (with “Disable Outputs”, “Bypass”, or “Output level inactive”. For any maintenance work the compressed-air and power supply of the machine must always be disconnected, and any existing pneumatic cylinders must be vented.

Safety Information for Commissioning

DANGER

To avoid any injuries due to energised parts in the electronics housing, the information in 5.1 and 5.2 must always be observed.



Safety Information for Storage and Transport



Always observe the information in paragraph 10 to avoid any transport damage and personal injuries.

Notes on Residual Risks



Electrical circuits may still be live even after having been isolated from the mains. Switch off immediately if a fault occurs.

Notes on Stable Standing Requirements



To avoid any loss of stable standing, the information for transport, commissioning and operation must always be observed. Always make sure that the fastening screws of the control unit are tight during operation. When storing or transporting the control unit, place it on the closed rear panel of the housing.

Consequences of Unauthorised Modification

Unauthorized modification or repair will invalidate all manufacturer declarations and guarantees.

Improper Use

For other applications as enumerated in 4.1 the control unit is regarded as inadmissible operation. Improper use also includes operating the equipment with excessive mechanical, static or dynamic loads (e.g. heavy machine parts or strong vibration). It is furthermore not permitted to inspect any aggressive materials on the conveyor, such as materials containing lyes, acids, and solvents, or materials that react to electromagnetic fields, or living persons or animals, and to operate the system in an Ex protection area.


Commissioning

Mechanical mounting


- Ensure stable and non-vibrating installation, inside mounting and operation. Do not install the system in an explosion proof zone.
- Do not install the detection coil and the electronic unit in the vicinity of electromagnetic interference fields (large electric motors and frequency converters!) The distance depends on the power consumption of the motor or of the frequency converter.
- Mount the control cabinet by using the provided mounting holes. I.e. at a wall or frame (dimensions are shown in the outline drawings). Pay attention to good stability, as the weight of the control unit is approx. 9 lbs.
- Never install the electronic unit in other switchgear cabinets, because this may lead to interference from other controls!
- Cable lengths may only be modified after consultation with Eriez. Use only original cables. Lay the connecting cable in fixed installation apart from other cables (e.g. fix it with nailing clips or lay it in a cable duct).
- If several metal detector systems are used, the distance of the detection coils must not be less than 6.5 ft, if these coils stand side by side. If the coils are arranged opposite to each other, the distance must not be less than 32.8 ft. These values apply to large systems; for smaller systems the distances may be reduced to 1.6 ft. If, for reasons of space, these distances cannot be observed, please contact Eriez service!
- Do not install the equipment in such a way that operation of the mains cut-off switch is hindered in any way!

Connection of the equipment

In order to meet CE conformity all cable outside of the housing has to be shielded. The shields must be grounded immediately after the cable gland.




Control / IO Electronics Board (Control Electronics Board)



Pos.	Connection	Type of Connection	Function																																								
(1)	“Mains/Option”	Connector for mains supply	L/N: Electronics power supply O1/O2: Optional 24V module power supply connector																																								
(2)	“Relay Metal”	Voltage free relay contact	Normal operation: Contacts 71 and 72 closed On metal detected: Contacts 71 and 74 closed																																								
(3)	“Relay Fault”	Voltage free relay contact	Normal operation: Contacts 81 and 84 closed In case of fault: Contacts 81 and 82 closed																																								
(4)	“Outputs”	Switching outputs 24V	<table border="1"> <thead> <tr> <th colspan="8">J5</th> </tr> <tr> <th>9</th><th>10</th><th>11</th><th>12</th><th>13</th><th>14</th><th>15</th><th>16</th> </tr> </thead> <tbody> <tr> <td>GND</td><td>LM</td><td>LB</td><td>LF</td><td>Mz</td><td>GND</td><td>GND</td><td>GND</td> </tr> <tr> <td>FU</td><td>24V</td><td>24V</td><td>24V</td><td>24V</td><td>MV1</td><td>MV2</td><td>MV3</td> </tr> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td> </tr> </tbody> </table>	J5								9	10	11	12	13	14	15	16	GND	LM	LB	LF	Mz	GND	GND	GND	FU	24V	24V	24V	24V	MV1	MV2	MV3	1	2	3	4	5	6	7	8
			J5																																								
9	10	11	12	13	14	15	16																																				
GND	LM	LB	LF	Mz	GND	GND	GND																																				
FU	24V	24V	24V	24V	MV1	MV2	MV3																																				
1	2	3	4	5	6	7	8																																				
<table border="1"> <thead> <tr> <th colspan="2">J5</th> <th colspan="2">Switching functions</th> </tr> <tr> <th colspan="4">MV = magnetic valve (↓=24V to GND or ↑=0V to 24V)</th> </tr> </thead> <tbody> <tr> <td>1 - 9</td> <td>↑, FU:</td> <td colspan="2">Not assigned</td> </tr> <tr> <td>2 - 10</td> <td>↓, LM:</td> <td colspan="2">Lamp metal</td> </tr> <tr> <td>3 - 11</td> <td>↓, LB:</td> <td colspan="2">Lamp operation</td> </tr> <tr> <td>4 - 12</td> <td>↓, LF:</td> <td colspan="2">Lamp fault</td> </tr> <tr> <td>5 - 13</td> <td>↓, Mz:</td> <td colspan="2">Ext. metal counter</td> </tr> <tr> <td>6 - 14</td> <td>↓ or ↑, MV1,</td> <td colspan="2">(after system setup)</td> </tr> <tr> <td>7 - 15</td> <td>↓ or ↑, MV2,</td> <td colspan="2">(after system setup)</td> </tr> <tr> <td>8 - 16</td> <td>↓ or ↑, MV3,</td> <td colspan="2">(after system setup)</td> </tr> </tbody> </table>	J5		Switching functions		MV = magnetic valve (↓=24V to GND or ↑=0V to 24V)				1 - 9	↑, FU:	Not assigned		2 - 10	↓, LM:	Lamp metal		3 - 11	↓, LB:	Lamp operation		4 - 12	↓, LF:	Lamp fault		5 - 13	↓, Mz:	Ext. metal counter		6 - 14	↓ or ↑, MV1,	(after system setup)		7 - 15	↓ or ↑, MV2,	(after system setup)		8 - 16	↓ or ↑, MV3,	(after system setup)				
J5		Switching functions																																									
MV = magnetic valve (↓=24V to GND or ↑=0V to 24V)																																											
1 - 9	↑, FU:	Not assigned																																									
2 - 10	↓, LM:	Lamp metal																																									
3 - 11	↓, LB:	Lamp operation																																									
4 - 12	↓, LF:	Lamp fault																																									
5 - 13	↓, Mz:	Ext. metal counter																																									
6 - 14	↓ or ↑, MV1,	(after system setup)																																									
7 - 15	↓ or ↑, MV2,	(after system setup)																																									
8 - 16	↓ or ↑, MV3,	(after system setup)																																									
(5)	“Inputs”	Switching inputs 24V	<table border="1"> <thead> <tr> <th colspan="8">J6</th> </tr> <tr> <th>25</th><th>26</th><th>27</th><th>28</th><th>29</th><th>30</th><th>31</th><th>32</th> </tr> </thead> <tbody> <tr> <td>GND</td><td>FEX</td><td>GND</td><td>DÜ</td><td>TEX</td><td>REX</td><td>MAN</td><td>MD</td> </tr> <tr> <td>24V</td><td>KÜ</td><td>24V</td><td>24V</td><td>24V</td><td>24V</td><td>24V</td><td>24V</td> </tr> <tr> <td>17</td><td>18</td><td>19</td><td>20</td><td>21</td><td>22</td><td>23</td><td>24</td> </tr> </tbody> </table>	J6								25	26	27	28	29	30	31	32	GND	FEX	GND	DÜ	TEX	REX	MAN	MD	24V	KÜ	24V	24V	24V	24V	24V	24V	17	18	19	20	21	22	23	24
			J6																																								
25	26	27	28	29	30	31	32																																				
GND	FEX	GND	DÜ	TEX	REX	MAN	MD																																				
24V	KÜ	24V	24V	24V	24V	24V	24V																																				
17	18	19	20	21	22	23	24																																				
<table border="1"> <thead> <tr> <th colspan="2">J6</th> <th colspan="2">Switching functions</th> </tr> <tr> <th colspan="4">24V, NPN or PNP switching</th> </tr> </thead> <tbody> <tr> <td>17 - 18 - 25</td> <td>KÜ:</td> <td colspan="2">Flap monitoring PNP or NPN (dep. on app)</td> </tr> <tr> <td>19 - 26 - 27</td> <td>FEX:</td> <td colspan="2">Fault external PNP or NPN (dep. on app)</td> </tr> <tr> <td>20 - 28</td> <td>DÜ:</td> <td colspan="2">Compressed-air monitoring NPN</td> </tr> <tr> <td>21 - 29</td> <td>TEX:</td> <td colspan="2">Test external NPN</td> </tr> <tr> <td>22 - 30</td> <td>REX:</td> <td colspan="2">Reset external NPN</td> </tr> <tr> <td>23 - 31</td> <td>MAN:</td> <td colspan="2">Manual separation NPN</td> </tr> <tr> <td>24 - 32</td> <td>MD:</td> <td colspan="2">Deactivate metal detection NPN</td> </tr> </tbody> </table>	J6		Switching functions		24V, NPN or PNP switching				17 - 18 - 25	KÜ:	Flap monitoring PNP or NPN (dep. on app)		19 - 26 - 27	FEX:	Fault external PNP or NPN (dep. on app)		20 - 28	DÜ:	Compressed-air monitoring NPN		21 - 29	TEX:	Test external NPN		22 - 30	REX:	Reset external NPN		23 - 31	MAN:	Manual separation NPN		24 - 32	MD:	Deactivate metal detection NPN								
J6		Switching functions																																									
24V, NPN or PNP switching																																											
17 - 18 - 25	KÜ:	Flap monitoring PNP or NPN (dep. on app)																																									
19 - 26 - 27	FEX:	Fault external PNP or NPN (dep. on app)																																									
20 - 28	DÜ:	Compressed-air monitoring NPN																																									
21 - 29	TEX:	Test external NPN																																									
22 - 30	REX:	Reset external NPN																																									
23 - 31	MAN:	Manual separation NPN																																									
24 - 32	MD:	Deactivate metal detection NPN																																									

Pos.	Connection	Type of Connection	Function												
(6)	“Jumper JP10”	Placement, connection monitoring MV1 – MV3 active / inactive	<table border="1"> <thead> <tr> <th>JP10</th> <th>Functions</th> </tr> </thead> <tbody> <tr> <td></td> <td>Jumper Plugged, monitoring inactive</td> </tr> <tr> <td></td> <td>Jumper open, monitoring active</td> </tr> <tr> <td>1 - 2</td> <td>MV1 connection monitoring</td> </tr> <tr> <td>3 - 4</td> <td>MV2 connection monitoring</td> </tr> <tr> <td>5 - 6</td> <td>MV3 connection monitoring</td> </tr> </tbody> </table> <p>Remove jumper when valve is connected</p>	JP10	Functions		Jumper Plugged, monitoring inactive		Jumper open, monitoring active	1 - 2	MV1 connection monitoring	3 - 4	MV2 connection monitoring	5 - 6	MV3 connection monitoring
JP10	Functions														
	Jumper Plugged, monitoring inactive														
	Jumper open, monitoring active														
1 - 2	MV1 connection monitoring														
3 - 4	MV2 connection monitoring														
5 - 6	MV3 connection monitoring														
(12)	“+24V external”	+24V, external supply of magnet valve connection	<p>Supply MV1/MV2/MV3 with external 24V Necessary when high-power valves are used, if total valve power >6W</p> <table border="1"> <thead> <tr> <th>JP3</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td></td> <td>Selection, supply of magnet valve connections</td> </tr> <tr> <td>2 - 3</td> <td>MV supply 24V internal</td> </tr> <tr> <td>2 - 1</td> <td>MV supply 24 V external through connector J13</td> </tr> </tbody> </table>	JP3	Function		Selection, supply of magnet valve connections	2 - 3	MV supply 24V internal	2 - 1	MV supply 24 V external through connector J13				
JP3	Function														
	Selection, supply of magnet valve connections														
2 - 3	MV supply 24V internal														
2 - 1	MV supply 24 V external through connector J13														

Control / CU Electronics Board (Evaluation Electronics Board)



Pos.	Connection	Type of Connection	Function												
(6)	“Receiver”	Connection for detection coil: Receiver	<table border="1"> <thead> <tr> <th>JP10</th> <th>Functions</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Receiver signal</td> </tr> <tr> <td>2</td> <td>Receiver signal</td> </tr> <tr> <td>3</td> <td>Reference ground for receiver signal</td> </tr> <tr> <td>4</td> <td>-5V</td> </tr> <tr> <td>5</td> <td>+5V</td> </tr> </tbody> </table>	JP10	Functions	1	Receiver signal	2	Receiver signal	3	Reference ground for receiver signal	4	-5V	5	+5V
JP10	Functions														
1	Receiver signal														
2	Receiver signal														
3	Reference ground for receiver signal														
4	-5V														
5	+5V														
(12)	“Transmitter”	Connection for detection coil: Transmitter	<table border="1"> <thead> <tr> <th>JP7</th> <th>Functions</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Transmitter voltage</td> </tr> <tr> <td>2</td> <td>Reference ground for transmitter voltage</td> </tr> <tr> <td>3</td> <td>Not assigned</td> </tr> <tr> <td>4</td> <td>Transmitter switch-over signal</td> </tr> </tbody> </table>	JP7	Functions	1	Transmitter voltage	2	Reference ground for transmitter voltage	3	Not assigned	4	Transmitter switch-over signal		
JP7	Functions														
1	Transmitter voltage														
2	Reference ground for transmitter voltage														
3	Not assigned														
4	Transmitter switch-over signal														

Electrical Performance

Potential-free Relay Contacts

250V 3A with alternating voltage

! For the potential-free relay circuits fusing must be provided outside the equipment.

Switching outputs (MV1, MV2, MV3)

Maximum current load: 250 mA

Switching outputs (LM, LB, LF, Mz)

Maximum current load: 150 mA

Switching Inputs


Connection of make contacts against +24 V,

connection of sensors (PNP, NPN)


total max. permissible current load 24V / 150 mA

Drawing of input / output connections

Switching Outputs - J5





Switching Inputs - J6



! At J5, J6 only circuits that are isolated from the mains supply by way of double insulation (SELV circuits) may be connected.

Electrical Connection of the Equipment

! Maximum cable length for external components, switches and sensors is 49ft. Only shielded cables should be used. The shields must be attached directly to the electronics housing.



Mains supply via control electronics board

1. Conductor 1 (black) to terminal L
2. Conductor 2 (black) to terminal N
3. Conductor PE (yellow/green) to earth connection

Mains Supply via Safety Socket

1. Connect the cable with mains plug to an existing socket.
2. After approximately 5 seconds the machine is ready for operation.



Mains Supply via Terminal Box

⚠ DANGER

The following procedures should only be undertaken by qualified personnel. Before removing cover plates etc. make sure the equipment is isolated from mains or external voltage.

⚠ DANGER


If the mains plug is removed, a terminal box and a suitable mains disconnecter switch with corresponding labelling/markings must be installed. This disconnecter switch must be easily accessible and must disconnect all poles from the mains.

⚠ DANGER

If mains supply connection is effected by way of a terminal box, external fusing with 16A(T) must be provided outside the equipment.

1. Remove mains plug.
2. Strip 2 in. length of insulation from cable and 0.4 in. from leads and attach cable cores.

Main Cable




- (1) Shield
- (2) Conductor
- (3) PVC Insulation
- (4) Isolation
- (5) PVC Covering

3. Feed Cable into connection box according to diagram to the right.

⚠ DANGER

Make sure that the mains supply is switched off. Use a suitable shutdown unit i.e. emergency switch.



- (1) Terminal Box
- (2) 3 Pin Terminal
- (3) Control Unit Mains Cable
- (4) Main Supply
- (5) Conductor 1 (Black) To Terminal L
- (6) Conductor 2 (Black) To Terminal N
- (7) Conductor PE (Yellow/Green) To Terminal PE
- (8) Shield To Terminal PE

4. Close the terminal box.

5. The unit is ready for operation approximately 5 seconds after switching on.

! IMPORTANT!

Connect the Shield to PE

Note:

The mains cable has a wire cross-section of 1.5 mm². The mains supply fuse protection should be set accordingly.

The electronic board contains no alternating mains fuse.

Behavior of Machine at Start Up

Lamps and Outputs During Start-Up Phase:

Output	Contact Status with Parameter "Metal at power on = inactive []"
LED Operation/ Fault	"Off"
LED Metal	"Off"
Metal Relay	Contacts 71 and 72 closed (equal to no metal alarm)
Fault Relay	Contacts 71 and 72 closed (consistent with fault status)
MV1/MV2/MV3 Switching Outputs	High active or Low active, depending on system setup
Lamp Interface	LM = Lamp Metal "Off" LB = Lamp Operation "Off" LF = Lamp Fault "Off" Mz = Metal Counter "Inactive"


Output	Contact Status with Parameter "Metal at power on = active [x]"
LED Operation/ Fault	"Off"
LED Metal	"On"
Metal Relay	Contacts 71 and 72 closed (consistent with metal alarm)
Fault Relay	Contacts 81 and 82 closed (consistent with fault status)
MV1/MV2/MV3 Switching Outputs	High active or Low active, depending on system setup
Lamp Interface	LM = Lamp Metal "On" LB = Lamp Operation "Off" LF = Lamp Fault "Off" Mz = Metal Counter "Inactive"

Lamps and Outputs after Start Up Phase

Approximately 5 seconds

Output	Contact Status
LED Operation/ Fault	"On"
LED Metal	"Off"
Metal Relay	Contacts 71 and 72 closed (equal to no metal alarm)
Fault Relay	Contacts 81 and 84 closed (equal to no fault status)
MV1/MV2/MV3 Switching Outputs	High active or Low active, depending on system setup
Lamp Interface	LM = Lamp Metal "Off" LB = Lamp Operation "On" LF = Lamp Fault "Off" Mz = Metal Counter "Inactive"

Relays - Operating Status



Menu/Operation

This chapter starts with a short manual and cross references in order to familiarise the reader with the most important settings. Following this, all setup menus are described.

General Operation

The control unit can be operated with 4 keys of the membrane keypad. These keys are used both for navigation in menu selections and for setting parameters.

Key	Function	Comment
	Several Functions	Menu Selection → down
		Parameter → decrease the value
	Several Functions	Menu Selection → up
		Parameter → increase the value
	Several Functions	Back to the highest menu level
		Exit parameter settings without any changes
	Several Functions Confirm/ Accept/ Select Function	Menu Selection → Confirm
		Parameter → Accept
	Select Individual Menu Items by Pressing the Key	<input type="checkbox"/> Function 1
		<input type="checkbox"/> Function 2
	Reset Mode	<input type="text" value="Automatic"/>
	<input checked="" type="checkbox"/> Activate a Function	Displayed Function → Activate
	<input type="checkbox"/> Deactivate a Function	Displayed Function → Deactivate
	Function Key	Activates the separation process at metal separators
	Function Key	Resets a metal message Resets a fault message

Quick Start

Language Selection (if required)

1. Turn on device, operating mask is displayed.
2. Press the  key.
3. Press the  key until you reach the end of the menu list ("Setup" menu list) and confirm this with the  key.
4. Press the  key until you reach the menu item that is marked with *) (Language*) and confirm this with the  key.
5. Use the  or  keys to select the desired language and again confirm your selection with the  key.

Note:

For the control unit there are two language versions with the following languages

Language Version 1

- German
- English
- French
- Italian
- Spanish
- Dutch
- Japanese
- Czech
- Russian
- Greek
- Swedish
- Turkish
- Polish
- Hungarian

Language Version 2

- English
- Chinese Traditional
- Chinese Simplified
- Korean
- (Japanese will be added in this language version)

Menu Structure

Overview of menu items and setting masks, starting from the main menu.











Main Menu



Menu Items:

- Change product
- Auto-Set
- Product Parameter
- Output
- Conveying Speed
- Setup


Output Menu Items






Output Menu:

- Output adjust
- Output lock
- Monitoring
- Output level
- Output options

Function Menu Items








Setting Menu Items



Product Selection:

001: to 010:



Setup Menu:

- Logbook
- Show counter
- Device-Info
- Revision
- Language*)
- Login
- Logout



Setup Menu

Setup Levels

There Are Currently 3 Set Up Levels

Level 0 → “Setup level standard” without “Code-No.”

The following options are available:

- Logbook
- Show counter
- Device-Info
- Revision
- Language*)
- Login
- Logout

Level 1 → “Setup level” with code “1000”

The following options are available:

- Logbook
- Clear logbook ¹⁰⁰⁰⁾
- Show counter
- Device-Info
- Revision
- Change password ¹⁰⁰⁰⁾
- Language*)
- Clock/Date
- Setup options ¹⁰⁰⁰⁾
- Units ¹⁰⁰⁰⁾
- Frequency deviation ¹⁰⁰⁰⁾
- Factory settings ¹⁰⁰⁰⁾
- Login
- Logout

¹⁰⁰⁰⁾ Additional menu items with login 1000



















Level 2 → “Setup level” with code “2000” (IO level)

The following options are available:

- Logbook
- Clear logbook
- Show counter
- Device-Info
- Revision
- Language*)
- Air pressure monitoring ²⁰⁰⁰⁾
- Flap monitoring or "Initiator" or "Light barrier" ²⁰⁰⁰⁾
- External error or "Eject/filling level" or "Eject" or "Filling level" or "Clip detector" ²⁰⁰⁰⁾
- Setup options
- Login
- Logout

²⁰⁰⁰⁾ Additional menu items with login 2000 and depending on the set and activated options in the Service menu (factory settings, device and system specific).

Overview 1















- German
- English
- French
- Italian
- Spanish
- Dutch
- Japanese
- Czech
- Russian
- Greek
- Swedish
- Turkish
- Polish
- Hungarian



Overview 2

In addition to the standard menu items the following menu items can be selected in setup Level 1



Setup Level 1, Code 1000



Overview 3





In addition to the standard menu items the following menu items can be selected in setup Level 2.

Setup Level 2, Code 2000









The control unit has two inputs. Depending on the factory settings and function corresponding settings can be made in the setup menu for sensor 1 and sensor 2.



Sensor 1



Sensor 2



Operating Mask



Displayed in normal operation mode.

Displayed information:

Current product name (top right)

Se: Sensitivity (0 - 100%)


PA: Product angle (0° - 180°)

Info field: Current time, status of outputs etc...

Signal: Current signal of the metal detector

Signal value >100 → Metal signal

Different displays:




The Control Unit needs approx. 5 sec. for the start-up process.

If the outputs are disabled via menu settings, the display will illustrate this by showing

Output OFF

In addition, the green operating/fault light is off and a log entry is created.



If metal detection is deactivated over the digital bypass, the display shows

Bypass

The Operation/Fault LED goes off (not operating), and an entry is made in the logbook.

This display appears in case of an error message. The Operation/Fault LED flashes red, and a corresponding entry is made in the logbook.

This example shows an error from air pressure monitoring.

When the cause of the error has been remedied, the error message can be reset by pressing the hardware RESET key.




Warning messages have no influence on the operation of the system.

Warning in case of

- Battery power too low or battery missing.

The Operation / Fault LED flashes green.



On detection of metal, the mask on the left is displayed, the red metal light comes on and a log entry is created.



Change Product



Starting from the operating mask, press the  key in the main menu to select the Change product menu item.


The Control Unit can save up to 10 different products and their corresponding parameters. This functionality enables quick product changes.



Select the desired product from the list with the  and  keys, and confirm your product selection by pressing the  key.

The system automatically changes back to the operating mask.

Press the  key to return to the operating mask without changing the product.




Product B can be used to change the system to factory settings without being able to make changes at the product parameters.

The menu items Auto-Set and Product parameter in the main menu can no longer be selected.



Auto-Set



Starting from the operating mask, press the  key in the main menu to select the Auto-Set menu item.



This input mask is displayed, if the menu level is password-protected. Passwords are set by the customer.

This function is used to quickly set the metal detector to the properties of a new product or of the operating environment.


Product memories 1 to 3 have fixed preset product parameters. Auto-Set only is possible for product memories 4 – 10. Product 1 is low sensitivity, Product 2 is medium sensitivity and Product 3 is high sensitivity.

 **Ensure that only metal-free products are being used.**



Starting from the main mask, press the  key to confirm your selection.


Press the  key to start the function, then convey the respective product several times, at least twice.



Press the  key to stop the function. If you continue to convey the product additional times, this has no influence on the result of the product parameters.




Press the  key to close the function.



In the Product parameter menu the “Sensitivity” and “Product angle” parameters can be further optimized manually.

Use the  and  keys to change the respective parameter, and then press the  key to confirm the value.



The signal display illustrates how recent changes affect the system’s performance.

The Control Unit is now optimized for the product and the environment.

Test the device with a metallic object.

Product Parameter


Starting from the operating mask, press the  key to select the product parameter menu.



In the Product parameter menu the “Sensitivity” and “Product angle” parameters can be further optimised manually.



This input mask is displayed, if the menu level is password-protected. Passwords are set by the customer.



Use the  and  keys to change the respective parameter, and then press the  key to confirm the value.

The signal display illustrates how recent changes affect the system’s performance.

 **Changes in this menu are only applied for the current product.**


Conveying Speed



Select “Conveying speed” with .



This input mask is displayed, if the menu level is password-protected. Passwords are set by the customer.




Use the  and  keys to set the conveying speed, and press  to confirm the value. Press the  key to cancel the process without making any changes.

The two figures in brackets show the optimal speed range that can be covered with the above setting.

 **Changes in this menu are only applied for the current product.**

Output

Starting from the operating mask, press the  key to select the Output menu.



Output menu for setting the outputs MV1/2/3 and MR1.

Use the  and  keys to select individual menu items, and then press  to open the menu item.

Press  to exit the sub-menu and change back to next higher menu level.


This input mask is displayed, if the menu level is password-protected. Passwords are set by the customer.




Output menu

- Output adjust
- Output lock
- Monitoring
- Output Level
- Outputs options

Output Adjust



Depending on the settings under menu item “Output options” the switching times for delay and duration of the outputs can be set here in a range from 0 to 60s in 50ms steps.



MV1/2/3 (magnet valves, 24VDC outputs) and MR1 (metal relay 1).

Example:

[] Outputs independent

All the times for delay and duration apply to all the outputs.

Use the  and  keys to set the respective times.


Confirm both input fields with  to save the times.

Press  to cancel the process without making any changes.


Example:

[x] Outputs independent

MV1, set delay and duration only for MV1 (MV2, MV3 and MR1 can be set in the same way).



Output Lock



Output lock means that after a metal event the outputs are activated for the set delay time, but are not automatically reset.


Resetting must be done by pressing the **Reset** key.

The option can be set for MV1/2/3 and MR1, and for the LM output (lamp metal).

Comment:

With "Reset mode [Manual]" all the outputs are "Locked" and the menu thus is not available.

Mask 1



Mask 1 with [] Outputs independent
Mask 2 with [x] Outputs independent


With **+** key [x] LM → Output "Lamp Metal" locked.

With **-** key [] LM → Output "Lamp Metal" without lock function.


Confirm all input fields with **+** to save the functions.

Press **Esc** to cancel the process without making any changes.

Mask 2



Monitoring



Monitoring can be set for the connection of magnet valve MV1/2/3. The connection is monitored for broken cable and short-circuit.

Example for MV1:

With **+** key [x] MV1 → MV1 monitoring activated.


With **-** key [] MV1 → MV1 monitoring deactivated.

Confirm all input fields with **+** to save the settings.

Press **Esc** to cancel the process without making any changes.



Output Level



Output level means that in case of a metal event the respective output is activated depending on the setting.

"High" output is activated.

"Low" output is deactivated.

"Inactive" no output level.

Mask 1



Mask 1 with [] Outputs independent

With **+** or **-** key MV1/2/3 [High] → All outputs high-active.

With **+** or **-** key MV1/2/3 [Low] → All outputs low-active.

Mask 2



Mask 2 with [x] Outputs independent

MV1/2/3 can be set independently.




MV2 and MV3 in addition can be set to [inactive].

Confirm all input fields with **+** to save the settings.

Press **Esc** to cancel the process without making any changes.



Output



In the “Output options” menu several functions can be set for the outputs MV1/2/3, MR1 and LM.

These functions have an influence on the masks and settings in other menu items.

- | | |
|-------------------------|--|
| [x] Outputs active | → Switching function in case of metal as set |
| [] Outputs active | → No switching functions in case of metal
No entry in the logbook
“Output OFF” display in the operating mask |
| [x] Outputs independent | → Duration and delay for every output |
| [] Outputs independent | → Duration and delay for all outputs |
| Reset mode [Autom.] | → Duration and delay
(metal message is reset automatically) |
| Reset mode [Manal] | → Only delay
(metal message is reset manually) |
| [x] Metal at fault | → Metal message also in case of a fault. |
| [x] Metal at power on | → Metal message until operating status. |

Example:

With **+** key [x] Outputs active


With **-** key [..] Outputs inactive

Confirm all input fields with **+** to save the settings.

Press **Esc** to cancel the process without making any changes.

Setup

Starting from the operating mask, press the key to select the Setup menu.



Use the **+** and **-** keys to select individual menu items, and then press **+** to open the menu item.

Press **Esc** to exit the sub-menu and change back to next higher menu level.


This input mask is displayed, if the menu level is password-protected. Passwords are set by the customer.

Setup menu


- Logbook
- Show counter
- Device-Info
- Revision
- Language*)
- Login
- Logout

! Changes in this menu are effective for ALL products

Logbook




Select "Logbook" with .



Scroll through the saved incidents with  and . All incidents are in chronological order and displayed with date and time.

Leave "Logbook" with .



The logbook contains 100 entries which are permanently saved.

The following information is available:

- Running number of the entry.
- Date and time of the incident.
- Message (error messages are marked with a .
- Optional: 2 lines of additional information (depending on entry).

ATTENTION


When the maximum number of entries is reached, the oldest entries will be deleted without asking.

The following messages and information are displayed in the logbook:

Type	Incident	Additional Information	Comment
Metal	Metal	- Global metal counter - Metal signal	
Info	Mains on/off		
	Product Change	- Old Product number - New Product number	
	Change of Product Data	- Current Pd. number - Product data group	For learning, product angle and sensitivity are also displayed
	Charge Change	- Change number	
	Outputs on/off		
	Metal Incident	- Metal Signal	Active During Test
	Time/Date Settings		
	Change of System Data	- System Data Group	
	EEPROM Grundinit		
	Bypass Active		
	RESET Error		
	Login	ID	
	Logout		
	Transmitter Temperature		
	Receiver Too High		
	EEPROM		
Error	Receiver too High	- Error Counter (Global)	
	Transmitter Over-Temp	- Error Counter (Global)	
	Flap Position	- Error Counter (Global)	
	Air Pressure	- Error Counter (Global)	
	Reject Container Full	- Error Counter (Global)	
	Reject Control	- Error Counter (Global)	
	Light Barrier	- Error Counter (Global)	
	EEPROM	- Error Counter (Global)	
	External Error	- Error Counter (Global)	



Clear logbook (Menu item requires login)



Select “Clear logbook” with .




Deleting the logbook requires confirmation

Cancel with  “no” and retain logbook.

Delete logbook with  “yes”.


Show counter



Select “Show counter” with .





Use the  and  keys to select the respective counter, and then press  to open the counter.




Available counters:


- **User counter**
Sums up all metal incidents regardless of product or batch changes until reset by user.
- **Metal counter**
Sums up all metal incidents.
- **Error counter**
Sums up all error incidents.
- **Product counter** (only in combination with trigger light barrier)
Sums up all conveyed products.
- **Global**
All incidents since launch of device
- **Product**
All incidents since selection of current product
- **Batch**
All incidents since start of current charge



Device-Info



Select "Device-Info" with .




The display shows the currently set detection frequency and the currently set operating mode.

- Pipe Scan
- RAPID (FF)
- Vacuum/pressure conveying
- PROTECTOR (CF, CFP)
- Belt conveyor
- C-SCAN DLS




Serial number of the CU electronics board




Voltage values of the CU electronics board

Nominal values
 - 5V, +/- 0.1V +5V, +/- 0.1V
 -15V, +/- 0.3V +5V, +/- 0.3V



Temperature values of CU and IO electronics boards

Nominal < 80° C Nominal < 80° C




Voltage values of the coil connection

Nominal >11V Nominal < 1.2A


Voltage values of the IO electronics board

Nominal values
 24V, +/- 0.4V +10V, +/- 0.4V 5.5V +/- 0.2V

Revision



Select "Revision" with .




The display shows the revision numbers of the installed hardware and software components of CU electronics board and IO electronics board.



Info about the operating system that is used (licence).

Press  to exit the menu.

Change password (menu item requires login)



Select "Change password" with .



Available passwords:

- **Change product** for menu
 - "Change product"
- **Auto-Set/Product** for menu
 - "Auto-Set"
 - "Product parameters"
 - "Conveying speed"
- **Parameter** for menu
 - "Outputs"
- **Setup** for menu
 - "Setup"
 - "Service"



Use the  and  keys to enter the figures, and confirm each with .


Press  to exit the sub-menu and change back to next higher menu level.

A password assigned previously has to be entered before a new one can be assigned.

Language




Select "Language" with .



Use the  and  keys to select the desired language, and confirm it with .

Clock/Date (menu item requires login)



Select "Clock/Date" with .




Change digits with  and .


Press  to jump to the next value, after setting the year, save changes and exit the menu .

Cancel without changes with .

Setup Options (Menu Item Requires Login)



Select "Setup options" with .




With  key [x] Stop&Go mode active.

With  key [] Stop&Go mode inactive.


Confirm with .

[x] Stop&Go mode: This option is necessary if products, for example due to a belt stop, can stop in the coil.

Units (menu item requires login)



Select "Units" with .



This menu item can be used to configure the country-specific format of the conveying speed unit and of the date/time format.

Use the  and  keys to set the respective unit.


Confirm both input fields with  to save the settings.

Press  to cancel the process without making any changes.

Formats for conveyor speed: <ul style="list-style-type: none">- m/s- m/min- ft/s- ft/min	Formats for date and time: <ul style="list-style-type: none">- dd.mm.yyyy- yyyy-mm-dd- mm/dd/yyyy
---	---

Frequency deviation (menu item requires login)

When several Eriez metal detectors or metal separators with the same search frequency are used near each other, an interference in the signal can occur. To prevent this, a frequency deviation can be selected. Changes of pre-installed values should only be made after consulting Eriez.



Select "Freq. deviation" with .



Use the  and  keys to set the desired value, and confirm it by pressing .


Exit without changes with .

The maximum approved range has been defined by Eriez in final clearance.



Factory settings (menu item requires login)

With this menu item the system can be reset to the factory settings at the time of delivery. System data and all product memories will be reset to factory settings, i.e. to the settings at the time of delivery.



Select "Factory settings" with .




For safety reasons you will be prompted to confirm the process.

Press  "No" to cancel the process, the current settings will remain unchanged.

Press  "Yes" confirm the process, system and product data will be reset to the settings at the time of delivery.

Login

Protected parts of the Setup menu can be accessed by way of the "Login" and "Logout" menu items. In every-day operation these items usually are not needed and are therefore hidden.




Select "Login" with .



Use the  and  keys to enter the respective figure and confirm each with .

To exit the menu, sign out or restart the device.


Logout



Select "Logout" with .

Changes to operating mask and deactivates the entered code.

Air pressure monitoring (option) (menu item requires login)



Select "Air pressure mon." with .




The air pressure can be monitored.

0.0s deactivates the monitoring.

A value different to 0 sets the maximum time, in which the air pressure can drop below the limit set in the pressure controller without creating an error message.

The value can be varied in steps of 2.5s up to a maximum of 10.0s. Changing the factory pre-set value is usually.

Flap monitoring (option) (menu item requires login)



Select "Flap monitoring" with .



Flap monitoring can be configured in this menu.


0.0s deactivates the monitoring.

Values different to 0 set the time, which the flap may not extend when switching from normal position to reject position and vice versa.


The value can be varied in steps of 0.1s up to a maximum of 10.0s.

Changing the factory pre-set value is usually not required.

External error (option) (menu item requires login)



Select "External error" with .



This menu item is used to configure the external error input.


[x] Activated

[] Deactivated

The error signal only is accepted after the set delay time (error filter).

The value can be set up to 25.0s in 0.05s steps.

Ejection monitoring (option) (menu item requires login)



Select "Ejection monitoring" with .



In the ejection monitoring menu item the input, depending on the application, can be assigned different functions, e.g. level monitoring.

This item is used to configure level monitoring.

[x] Activated

[] Deactivated

Level monitoring

Shows whether the reject container still has free capacity.

Errors and Error Remedying

WARNING

If you should have any questions, or if there should be any malfunctions, please contact the manufacturer.

WARNING

If you have any questions, please state the equipment type and serial number!

ERIEZ Telephone: 814-835-6000

Error Messages

In case of an error the Operating/Fault LED at the control panel flashes red, a corresponding error message appears on the display, and the fault relay (see page 18) drops. If the system is correspondingly configured, a metal alarm will also be activated.

Receiver Voltage Too High

This message appears if the signal that is received from the detection coil has a too high voltage.

Possible Causes	Remedy
Big metal part (e.g. aluminium ladder, screwdriver, hammer, bracelets) directly beside or in the detection coil.	Check the detector head and the surrounding. Sometimes metal parts can be found inside or underneath the belt.
Improper installation of the search coil.	See operating instructions Detection coil: "Installation".

Receiver Faulty

This message appears if the receiver connection cable is interrupted.

Possible Causes	Remedy
Receiver cable between control unit and detection coil is interrupted.	Check the receiver cable for interruptions. Replace it, if necessary. Check the connectors of the connection cable. If necessary, plug them on/ fix them again.

Transmitter Faulty

This message is displayed if the transmitter signal is not detected or the connection to the detector is broken.

Possible Causes	Remedy
Transmitter cable between control unit and detector has a short circuit or transmitter frequency is incorrect.	Disconnect transmitter cable at the detector (triax cable) and measure with Ohm meter: replace if necessary or check transmitter frequency.

Transmitter Over Temperature

Possible Causes	Remedy
CU electronics board defective.	Replace the CU electronics board.
Coil or transmitter connection board defective.	Contact Eriez service.

Hardware CU

Possible Causes	Remedy
Self-monitoring (self-test) has detected an error on the CU electronics board.	Replace the CU electronics board.

Hardware IO

Possible Causes	Remedy
Self-monitoring (self-test) has detected an error on the IO electronics board.	Replace the IO electronics board.

Communication IO

This message appears if communication between CU electronics board and IO electronics board is interrupted (see spare parts drawing, pg. 45) and data exchange is no longer possible.

Possible Causes	Remedy
Interface module defective.	Replace the CU and/or IO electronics board.

Watchdog

Possible Causes	Remedy
Software error of the CU electronics board.	If this occurs several times, contact Eriez service.

Memory Error

Possible Causes	Remedy
System and product data memory defective.	Check whether the memory module is properly inserted in the socket (see page 10).
	If necessary, replace the memory module. Then select menu item "Factory settings".
	Replace the CU electronics board.

Short Circuit MV

This message is displayed if there is a short circuit in the magnetic valve switching outputs.

Possible Causes	Remedy
Short circuit or connection broken to magnetic valve 1.	Check valve cable for breaks and renew if necessary.
	Check valve cable plug and socket connections, remove and reinsert if necessary.

Connection MV

This message is displayed if there is a break in the magnetic valve switching outputs.

Possible Causes	Remedy
Short circuit or connection broken to magnetic valve 2.	Check valve cable and connectors with Ohm meter for short circuit, replace if necessary.
	Check magnetic valve resistance which should be 320...340 Ω (or 100...140 Ω for pusher application).

Air Pressure

Possible Causes	Remedy
Appears on display if the air pressure monitor responds or the connection to the sensor is interrupted.	Check the connection cable to the pressure sensor.
No air pressure or air pipe broken.	Check air supply.
Operating threshold of pressure monitor is set too high.	Adjust pressure monitor.

Diverter Position

Possible Causes	Remedy
Appears during reject operation of the diverter, if signal timing is not correct, diverter is broken diverter too slow.	Fix the diverter mechanics Check diverter if tight or wedged pieces Check air pressure (min. 5 bars)
	Forward and return time set too short. Connection to the sensors defective.

Sensor 1 Faulty

Possible Causes	Remedy
Error signal at the sensor 1 connection on the IO electronics board (terminal 18). Sensor connection for flap monitoring. Sensor connection for initiator – distance measurement. Sensor connection for sync – light barrier.	Find the cause of the error and remedy it.
	Replace the sensor.

Sensor 2 Faulty

Possible Causes	Remedy
Error signal at the sensor 2 connection on the IO electronics board (terminal 26). Sensor connection for external error. Sensor connection for initiator – filling level. Sensor connection for initiator – clip detector.	Find the cause of the error and remedy it.
	Replace the sensor.

Filling Level

Possible Causes	Remedy
The container is full.	Empty container.
Is the sensor faulty?	Change sensor.
The sensor is not connected, or the connection cable is interrupted.	Check the sensor connection.



Undefinable Activation of the Switching Outputs

Possible Causes	Remedy
Improper installation of the search coil	See operational manual detector coil: "Mounting"
<p>Conveyor Belt Systems: Intermittent contacts on the conveyor frame for example due to:</p> <ul style="list-style-type: none"> Loose guide plates Loose screw connections on the frame parts <p>Changing contact resistance on the tension and deflection roller bearings or on the drive roller.</p> <p>Certain parts of the conveyor belt are conductive:</p> <ul style="list-style-type: none"> Contaminated with metal (welding spatter, metal chips, abraded material...). Belt junction causing metal alarm to signal even when no product on moving conveyor. 	<p>Check and tighten all screw connections. If necessary weld frame parts.</p> <p>Insulate cross connections or tension and deflection rollers on one side.</p> <p>Clean conveyor belt of all residue.</p> <p>If necessary replace conveyor belt.</p>
<p>Circular Coils: Mechanical contact between scanning pipe and detection coil.</p>	Observe a minimum distance of 10mm between pipe and coil. If necessary use a scanning pipe with smaller diameter.
Sensitivity setting too high.	Repeat product teach-in procedure, if necessary reduce sensitivity manually.
Metal particles hard to identify due to corrosion or encapsulation.	Check processed material carefully, if necessary pass through detector again.
Loose contact at the detector cables.	Check connections.
Material or conveyor statically charged (cracking sound heard at the detection coil).	Prevent static by additional earthing (please consult manufacturer) or by using ion spraying devices.

External Error

Possible Causes	Remedy
<p>Error signal at the external error input of the IO electronics board.</p> <p>Alarm message of the frequency inverter. For example: Thermal contact of motor protection.</p>	Find the cause of the external error and remedy it.


Replacing the Battery Backup

DANGER

Because of energised components in the electronics housing there is a risk of injuries due to electric shock or burns.

Therefore such work may only be performed by a qualified electrician under strict observation of the attached warning labels and with due regard to standard approved rules of electrical engineering.

- As a precaution, make a backup copy of the logbook entries.
- Do not turn off the power supply to avoid any loss of data.
- Open the cover of the electronics housing.



Procedure - Replacing the backup battery:

Button cell CR2032 (for STE article number 33011070):


- Carefully remove the old backup battery a) from its holder
- Insert the new backup battery.
- Always observe the correct polarity (positive pole on top)
- Close the cover of the electronics housing again.
- Check whether the date and time settings are still correct, and whether the logbook entries are still there.

 If the backup battery is not replaced in time, the following data will be lost:

Date and time.

Replacement of Electronics Board

The Control Unit consists of the following three boards: **CU electronics board (2)**, **IO electronics board (5)** and **display board (7)**.




Replacing the CU electronics Board

1. Disconnect voltage supply and external circuits and open the cover at the electronics housing.
2. Remove connectors and remove the fastening screws (1).
3. Remove the CU electronics board (2).
4. Install the new board in reverse order, **but do not connect mains power supply!**

! The data memory is located on the CU electronics board (evaluation electronics board). The memory contains all device and product parameter settings. If this memory device is transferred to a new board no new settings must be performed.

Transferring All Settings



- (a) New Controller Board
- (b) Old Controller Board

Procedure:

1. Remove the data memory module from the new (already installed) CU electronics board (a) and place it aside.
2. Remove the data memory module from the old CU electronics board (b) and insert it in the memory socket of the new CU electronics board (a).
3. Switch on power supply. The new board runs with the "old" settings.

! When the system and product data memory module is replaced, the date and time information will not be adopted (because this information is saved in the battery-powered memory)

Replacing the IO Electronics Board

1. Disconnect voltage supply and external circuits and open the cover at the electronics housing.
2. Remove the used connectors and remove the fastening screws (1), (3) and (4).
3. Remove the CU electronics board (2).
4. Remove the IO electronics board (5).
5. Install the new IO electronics board (5) and the other components in reverse order!

Replacing the Display Board

1. Disconnect voltage supply and external circuits and open the cover at the electronics housing.
2. Remove the used connectors and remove the fastening screws (6).
3. Take out the display board (7).
4. Install the new board in reverse order!

Maintenance and Cleaning

DANGER

Prior to cleaning turn off the system with the master switch and disconnect the system from the mains voltage.

Maintenance

The control unit is maintenance-free, yet it is still appropriate to inspect the equipment in regular intervals:

- Are all the fastening screws tight?
- Is the housing seal in perfect condition, and does it provide proper sealing?
- Also check all the cables for possible damage (e.g. at the cable sheath).

Cleaning

Hints for cleaning

- Please ensure you follow the instructions below.
- Specific machine components must be cleaned with specific substances. Please use the correct materials and clean at regular intervals as suggested.
- If the building is being cleaned ensure the machines are covered up.

The following must not be used for cleaning:

- Sharp, hard or pointed objects
- Water or steam jet appliances
- Compressed air
- Hazardous and solvent-containing materials
- Cleaning agents that may attack the materials used

Cleaning instructions

For cleaning purposes we recommend that you use warm water with approved cleaning agents for the respective application, and a soft, lint-free cloth. Once every week the coil shaft should be thoroughly cleaned, removing any dirt accumulations and deposits. After cleaning wipe up any remaining drops of water with a dry, non-fibrous cloth until the coil shaft is dry. From time to time apply oil to the stainless steel framework (e.g. Nirostol 55 cleaning and maintenance oil which meets food industry standards).

Care advice for stainless steel

Only high-quality stainless steel is used in the systems. To prevent rust on the high-grade steel parts do not use substances containing chloride (e.g. cleaning or disinfecting products) or operate the machine in an atmosphere containing chloride. If this is unavoidable the steel parts must be thoroughly rubbed down immediately afterwards with cleaning oil e.g. Nirostol 55 cleaning and maintenance oil (which meets food industry standards).

Important information for stainless steel models

Stainless steel models are extremely weatherproof and are therefore able to withstand most environmental conditions.

However, even stainless steel can be susceptible to a slight film of rust.

These deposits are caused by contact corrosion and can be removed by following the instructions below:


- Use a stainless steel cleaner: in principle any stainless steel cleaner may be used. Please ensure you read the instructions prior to use.
- Use only cleaning agents that are halogen-free (i.e. without chlorides and fluorides), and salt and hydrofluoric acid free.
- After each cleaning rinse the machine thoroughly with tap water
- Do not use the following: non-alloy materials or substances, abrasive cloths, cleaning agents containing salt or hydrofluoric acid, chrome, silver or brass cleaners.

Spare Parts

If you should have any questions please state equipment type and serial number

! Spare parts and wearing parts must always be obtained from the manufacturer or from a supplier that is certified by the manufacturer.

Spare Parts View



Spare Parts List

Item No.	Part	Part No.	Art No.	Sp/Con
1	Electronics Housing	Z0065803	77080254	Sp
2	Cable Threaded Joint MS-M 20x1.5		33001012	Sp
3	Cable Threaded Joint MS-M 16x1.5		33001010	Sp
4	Nut 50220 M for cable threaded joint		33001004	Sp
5	Nut 50216 M for cable threaded joint		33001002	Sp
6	Distance bolt M4x20		31160822	Sp
7	Distance bolt M4x10		31160820	Sp
8	Bush		77101378	Sp
9	Hexagon Nut M4		31160908	Sp
10	Wall mount for control cabinet (accessory)		08006717	Sp
11	Distance bolt M4x15		08023239	Sp
12	IO electronics board		77103219	Sp
13	Membrane keypad		77100328	Sp
13	Membrane keypad		77100326	Sp
14	Display		33015460	Sp
15	CU electronics board		33015446	Sp
16	AC/DC converter		33013134	Sp
17	Hexagon screw M8x20		15090400	Sp
18	Screw plug M20x1.5		33001018	Sp
19	Screw plug M16x1.5		33001016	Sp
20	Memory module (data memory)		77100949	Sp
21	Hexagon nut M8x8		15083200	Sp

*Sp/Con = Spare Part / Consumable

Shipping, Preservation, Waste Disposal, Transport, Storage

Shipping, Preservation, Waste Disposal

WARNING

Choose packing that is suitable for the type and size of unit, taking into account whether the shipment is for export by sea or airfreight, or for national or international road transport. The packing material must protect the goods from all damage under normal transport conditions.

WARNING

Depending on the size, weight and nature of the goods packing in cardboard boxes, boxed pallets etc is only suitable for road transport.

Use reinforced card, corrugated cardboard, blister packing and shredded paper to fill and protect the goods.

Electrostatic sensitive components (electronic boards, electronic modules, etc.) must be packed in antistatic foil or foil bags prior to packing! (this is essential!)

Stick additional warning labels on the outside of the packaging e.g. "Attention, electronic equipment, do not drop," etc. The packing should be sealed with adhesive tape and, where the weight exceeds 50 kg, additionally with wrapping tape.

WARNING

When packing for international road transport use the instructions above (see above). Larger and heavier shipments must also be protected as for export in wooden crates. Care must be taken to ensure that the goods inside the packing are protected against corrosion.

Any parts that will corrode easily must be wrapped in oil paper or corrosion-protective foil. Care must be taken to prevent the components moving around within the packaging.

WARNING

International air freight shipments must be packed in wooden crates or on export pallets.

Care must be taken that the goods are secure and well-protected inside the packing. Any parts liable to corrode must be wrapped in oil paper, protective foil or sprayed with anti-corrosion spray.

WARNING

Sea-freight must be packed in seaworthy export crates. These crates can be obtained from specialist suppliers.

The crates must be lined with oil paper to make them resistant to sea water and prevent corrosion. In addition the goods must be protected against corrosion by use of a spray or be wrapping in protective foil.

Care must be taken to ensure that the goods cannot move around inside the crate.

After packing the sea-freight crates must be properly closed.

The sea crates must also be fastened externally with securing tapes.

During loading care must be taken not to damage the external packaging.

The carrier must certify that the shipment has been accepted and loaded correctly by detailing this on the bill of lading, loading list etc.

WARNING: WASTE DISPOSAL

Observe the national waste disposal regulations.

Transport

WARNING

In order to avoid injury or damage to the unit it must be handled properly. In addition to following the instructions below, general health and safety good practice and specific accident prevention guidelines should be observed


For correct handling and storage comply with the following symbols:




Protect Against Moisture



Careful: Glass



Up



Center of Gravity

WARNING

Do not lift the metal separator at the reject mechanism.

For lifting, attach strong lifting straps at the frame of the metal separator.

Do not compress the side walls of the unit or any attached parts by pulling obliquely on ropes or chains.

Only remove handling safeguards once all installation work has been completed.

When handling in a loading area make sure the unit cannot topple over or slip.

Damage caused during transportation must always be reported to the manufacturer.

Storage

WARNING

If possible the unit should be stored in a closed room until final installation.

If the unit is stored in the open it must be covered over with tarpaulins and open underneath, to allow condensation to drain off.

Avoid any higher temperature fluctuations. It is possible that condensed water that has formed in the packing cannot properly drain and may corrode equipment surfaces. If a formation of condensed water cannot be avoided, suitable desiccants e.g. in the form of bags must be placed in the packing.

If the unit has been packed for transportation by sea the packaging must not be damaged or opened during transit and storage.

For storage temperature and permissible air humidity please refer to the technical data sheet.


For correct storage comply with all storage and handling symbols:



Protect Against Moisture



Careful: Glass



Up

Accessories

- UL/CSA certificate

Eriez and Eriez Magnetics are registered trademarks of Eriez Manufacturing Co, Erie, PA

©2015 Eriez Magnetics

All Rights Reserved



World Authority in Separation Technologies

Headquarters: 2200 Asbury Road, Erie, PA 16506-1402 U.S.A.

Telephone: 814-835-6000 • 800-345-4946 • Fax: 814-838-4960 • International Fax: 814-833-3348

Web Site: <http://www.eriez.com> e-mail: eriez@eriez.com

Manufacturing Facilities: AUSTRALIA • BRAZIL • CANADA • CHINA • INDIA • JAPAN • MEXICO • SOUTH AFRICA • UNITED KINGDOM • UNITED STATES