

Installation, Operation and Maintenance Instructions



P-REX[®] **(Permanent Rare Earth Xtreme[®] Drum Magnet)**

ERIEZ MAGNETICS HEADQUARTERS: 2200 ASBURY ROAD, ERIE, PA 16506-1402 U.S.A.
WORLD AUTHORITY IN SEPARATION TECHNOLOGIES

Introduction

This manual details the proper steps for installing, operating and maintaining the Eriez P-REX® Drum Magnets.

Careful attention to these requirements will assure the most efficient and dependable performance of this equipment.

If there are any questions or comments about the manual, please call Eriez at 814/835-6000 for Scrap Drum assistance.



CAUTION

Safety labels must be affixed to this product. Should the safety label(s) be damaged, dislodged or removed, contact Eriez for replacement.



CAUTION - STRONG MAGNET

This equipment includes one or more extremely powerful magnetic circuits. The magnetic field may be much stronger than the Earth's background field at a distance several times the largest dimension of the equipment.

- If you use a heart pacemaker of similar device you must never approach the equipment because your device may malfunction in the magnetic field, with consequences up to and including death.
- To avoid serious pinch-type injuries caused by objects attracted to the magnet, keep all steel and iron objects well away from the equipment. Do not allow hands, fingers, and other body parts to be caught between the equipment and "workpiece" being lifted.
- Keep credit cards, computer disks, and other magnetic storage devices away from the equipment because magnetically stored information may be corrupted by the magnetic field.
- Keep electronic devices, such as computers or monitors, away from the equipment because exposure to the magnetic field may result in malfunction or permanent damage to such devices.

Contact Eriez if you have a question regarding these precautions.

Table of Contents

ERIEZ P-REX DRUM MAGNET

PREFACE.....	4
SAFETY NOTICE.....	4
GENERAL DESCRIPTION.....	5
DRIVE.....	6
ELECTRICAL.....	6
INSTALLATION.....	7
FEED TO THE DRUM.....	10
OPERATION AND ADJUSTMENTS.....	12
MAINTENANCE.....	13
TROUBLESHOOTING.....	17
BEARING REMOVAL.....	18
ADDITIONAL MATERIAL.....	20



Preface

Before starting the drum installation, read and understand this entire manual.

If you have any questions at this point, contact your ERIEZ representative or call the CUSTOMER SERVICE DEPARTMENT of ERIEZ at 814-835-6000.

This manual covers the following listed sizes and configurations of ERIEZ P-REX DRUM MAGNET SEPARATORS.

DRUM SIZES

DRUM DIAMETER	FACE WIDTH
48 x	48
	54
	60
	66
	72
	84
	96
108	
60 x	48
	54
	60
	66
	72
	84
	96
108	
72 x	48
	60
	72
	84
	96
108	

Drum Configurations

1. Scrap Drum with supporting frame and drive assembly.
2. Scrap drum without supporting frame and drive.

Safety Notice

P-REX drum magnets are normally positioned adjacent to belt conveyors, vibrating feeder pans, and delivery and take away chutes.

Rotating magnetic drums have wiper bars attached to the outside of the revolving drum shell. These moving wipers, the rotating drum heads, the conveyed, possibly sharp, material moving and bouncing onto, over, and off the drum, along with allied moving equipment, all combine to make the area near the drum a HAZARDOUS AREA.

ERIEZ MAGNETICS has no control over this area. We strongly emphasize that the drum installation should be away from normal personnel travel and working zones.

It may be necessary for the user to install protective guarding, fencing, barriers, or other devices to suit the specific installation in order to protect personnel.

A hood, enclosure, or other "fencing-off" means can apply. If used, the hood or other enclosures must be able to be lifted off or otherwise opened so normal maintenance and adjustments can be performed.

BUT whether the drum is open or enclosed, workers must be instructed as follows:

WARNING

Shut down and lockout all power to the drum and drive motor and to all power driven equipment in the drum area prior to performing maintenance, cleaning or adjustments in this area.

Failure to observe this warning could result in severe personal injury or death.

Warning, caution plates and decals on the magnet must not be removed or painted over. These must be followed, should the safety labels be damaged, dislodged, or removed. Contact Eriez for a replacement.

This caution is repeated in the INSTALLATION section of this manual.



General Description

⚠ CAUTION - STRONG MAGNET!

This equipment includes one or more extremely powerful magnetic circuits. The magnetic field may be much stronger than the Earth's background field at a distance several times the largest dimension of the equipment.

- **If you use a heart pacemaker or similar device you must never approach the equipment because your device may malfunction in the magnetic field, with consequences up to and including death.**
- **To avoid serious pinch-type injuries caused by objects attracted to the magnet, keep all steel and iron objects well away from the equipment. Do not allow hands, fingers, and other body parts to be caught between the equipment and "workpiece" being lifted.**
- **Keep credit cards, computer disks, and other magnetic storage devices away from the equipment because magnetically stored information may be corrupted by the magnetic field.**
- **Keep electronic devices, such as computers or monitors, away from the equipment because exposure to the magnetic field may result in malfunction or permanent damage to such devices.**

Contact Eriez if you have a question regarding these precautions.

An ERIEZ DRUM is used to separate mixed ferrous and nonferrous materials that are fed to it in a continuous stream. The two materials will leave the drum in two separate streams. If there are items in the feed stream that are integral assemblies of ferrous and nonferrous components, the drum can "see" them either way depending on many factors. These factors are: the assembly orientation as it approaches the drum, sizes and weights of the ferrous and nonferrous parts of the assembly, and shape of the assembly, So it is important to shred and sort the feed material for the most efficient separation. The volume of the stream fed to the drum, the characteristics (size, shape, mix ratio) of the mixed materials, and the overall system layout, all determine what size drum and what internal magnet element are supplied.

The internal magnet element is a permanent magnet, and its arc position inside the drum also relates to the feed position and system layout.

The efficiency of the separation will be determined by the factors described above and how they relate to each other. For example: the position of the feed to the drum and the exact location of the pickup zone of the magnet element inside the drum have major impact on resulting separation efficiency, for this reason, both these important factors have built in adjustments.

There are additional factors that can affect efficiency. These include speed of the feed stream to the drum, rotation speed of drum, pickup point distance from drum shell to feed stream, and ambient conditions.

The drum consists of a heavy duty rolled manganese steel shell with equally spaced inverted "V" wipers (cleats) across its face, two stainless steel heads, a continuous through shaft, and the internal magnet element.

Other components are element-adjusting arm and turnbuckles, bearings, driven sprocket, and shaft clamp blocks.

A wear wrap installed over the drum shell can be supplied as an option.

Another option is a structural steel frame with drive assembly that makes up a ready to install drum/frame/drive assembly.

The unit that has been supplied, drum only or drum/frame/drive assembly is shown on an outline drawing supplied with the order. The outline drawing also shows the positions of the feed to the drum and the two streams exiting the drum.



Drive

The range of drum diameters and drum widths with any of the different magnetic elements can be supplied as a complete ready to install assembly of drum/frame/drive or as a drum only. Drives for both are described below.

Drive Supplied as Part of the Drum/Frame/Drive Assembly

This drive is furnished complete, factory adjusted and aligned. The drive chain and sprockets are guarded. Drip lubrication provisions are built into the chain guard. The guard is split and can be opened if a brush-on chain lubrication is selected.

If an optional zero speed switch has been included, it has been mounted on the guard to indicate that the drum is rotating.

Drive Furnished and Installed by the User

Use a drive gear motor (or motor plus gear reducer) that meets the installation requirements for horsepower required (see chart), ambient temperature, ambient conditions, and CLASS II service factor.

NOTE: A rare earth magnetic drum has a minimum horsepower required as a function of the RPM.

Furnish a drive sprocket on the gear motor and a drive chain. These will drive the split Type A sprocket that is mounted on one of the drum hubs. Match the drive sprocket and chain to the supplied driven sprocket specs on the outline drawing in the back of this manual.

Furnish an enclosed chain guard. The guard will have to be split horizontally so it can be assembled in place. This enclosure must be designed to protect personnel and to prevent any piece of the feed and conveyed material from bouncing into the chain and sprocket area.

If user is supplying the chain guard use a non-magnetic material such as 304 stainless steel.

Provide for chain lubrication either with an oil reservoir outside the guard or with a guard design that can be opened for brush on lubrication. Observe power shut down and lockout as described in the *Safety Notice* section of this manual before opening the guard.

If a zero speed switch is to be included in the user supplied drive assembly, its purpose is to verify that the drum shell is revolving. It can “read” the revolving drum head or the driven sprocket on the drum head.

The following tabulation will assist in selecting components for the user supplied drive system:

TABLE 1

DRUM DIAMETER	FACE WIDTH	MOTOR H.P.*	DRUM ROTATION SPEED*
48 x	48	10	19.7 rpm (250 fpm)
	54	15	
	60	15	
	66	15	
	72	15	
	84	20	
60 x	96	20	15.8 rpm (250 fpm)
	48	20	
	54	20	
	60	20	
	66	20	
	72	25	
72 x	84	25	13.2 rpm (250 fpm)
	96	30	
	48	35	
	60	35	
	72	40	
	84	40	
	96	45	

*Other H.P. and RPM may be recommended based on shell design, wear wrap design, or ferrous loading onto drum shell. Do not exceed drum speed outlined as magnet damage may occur.

Electrical

Protection

Provide branch circuit protection, motor protection, and wiring all in accord with the National Electric Code and/or other applicable Local Codes.

Power to Drive Motor

Connect power to the motor junction box according to the diagram inside the junction box.



Installation

Because either a drum only or a complete drum/frame/drive assembly has been supplied, the installation section of the manual must treat these two very different units separately.

Note these cautionary points that apply to both type units:

1. Since the drum's magnetic element is a permanent magnet workers must be aware that ferrous tools, chains, cables, or any loose ferrous items will be attracted, and accelerate to the drum shell surface. Do not get hands, clothing, or any part of the body between the drum shell surface.
2. Do not allow workers to walk, stand, or set heavy objects on the drum shell (or wear wrap) O.D. The clearance between the I.D. and the stationary internal magnet element must not be reduced.
3. Do not set the drum down on the outside of the shell (or wear wrap) surface. Support the drum by the clamp blocks located at each end of the drum.
4. For the drum only unit: The magnetic element inside the drum is free to swing while the drum is being lifted and moved. Lift and travel must be smooth and steady with no sudden starts and stops.

For the drum/frame/drive assembly, the magnetic element inside the drum is locked into position by the adjusting arm turnbuckle at this point. It cannot swing inside the drum. But use a smooth and steady lift and travel because the entire unit being lifted is not a balanced assembly.

5. The drum only or the drum/frame/drive must be installed in relation to the feed conveyor or feeder pan that delivers material to the drum. See the outline drawing for recommended positioning

There must be plus or minus 3" (75 mm) of both vertical and horizontal adjustment of the drum available and built into the drum supporting frame. Whether the drum frame is supported from overhead or below, this adjustment must be available for fine tuning.

The listed 5 points must be reviewed and understood before moving forward with the lifting and installation operation.

Lifting and Installation of Drum Only Unit

Lift the drum from the shipping skid or crate with chains or lift straps placed around the shaft adjacent to the drum heads. Use a spreader beam so that the chains or straps are vertical and free of the drum heads. **DO NOT LIFT ON THE DRUM SHELL OR ON THE WEAR WRAP.**

Set the drum down so the shaft clamp blocks rest on the support frame.

For an alternate method you can remove the clamp blocks from the shaft while the drum is suspended and mount the bottom halves of the clamp blocks to the support framework. This will provide two saddles for which to locate the drum. Set the drum down located in its final axial position. Reattach the top halves of the clamp blocks before removing the lifting sling.

Now the magnet element inside the drum can be fixed into its operating position. Refer to the outline drawing.

The outline drawing illustrates the angle at which the magnet element is to be positioned inside the drum. It also illustrates where the element adjusting arm and turnbuckle anchor position is when the magnet element is in operating position.

Because the magnetic element will be hanging in the "down" or "free" position at this time, it is necessary to pull and lock it into its initial operating position. To do this, loosen (but do not remove) the bolts holding the two halves of the clamp blocks together. This will allow the shaft and, therefore, the element to rotate.

Push or pull on the adjusting arm. The magnetic element is heavy so mechanical assisters such as a block and tackle will be needed.



SEE CAUTION STATEMENT ON NEXT PAGE!



Installation (cont.)

! CAUTION

If the adjusting arm is released from the pushing or pulling device before the clamp blocks are retightened and without an auxiliary restraint in place, it will swing violently along with the heavy magnetic element inside the drum. This may cause severe personal injury including death to personnel in the path of the arm. Provide adequate auxiliary restraints to prevent such motion and require personnel to stay clear of the arm when the clamp blocks are loose.

Refer to Figure 1 to determine the appropriate orientation and rotation direction for your drum.




FIGURE 1

One of these nameplates is attached to your drum shaft. The shaded area shows the position of the magnet inside your drum. Introduce feed material to the drum surface near the Pickup Pole (MI). Be sure the drum rotates so that the ferrous material reaches the Pickup Pole (MI) BEFORE it reaches the Agitating Pole (M2) or the Bleedoff Pole (BO) as it is carried around the drum.

Firmly tighten (1120 ft-lb) both halves of the clamp blocks together and anchor the partially open turnbuckle to the support frame as illustrated. Only now can the block and tackle and restraints be removed.

The magnetic element is now in its initial operating position. Adjustments may be necessary to optimize recovery. How these adjustments are made is covered later in the *Operation and Adjustments* section of this manual.

Lifting and Installation of Drum/Frame/Drive Unit

To support the frame from overhead use chains, cables, or straps around the frame adjacent to the four lugs with the turnbuckles attached to them. (These hanging turnbuckles are not provided if the frame is to be supported from underneath so in this case you can lift directly from the lugs).

The hanging turnbuckles should be set at half open so there is plus or minus 3" (75 mm) of adjustment in them.

For overhead support, the lugs on the overhead structure must have several attaching holes to provide the required plus or minus 3" (75 mm) of horizontal adjustment.

The hanging arrangement described above will allow both vertical and horizontal adjustment of the position of the drum in relation to the feed conveyor or the feed pan.

For support from below the 3" (75 mm) plus or minus horizontal adjustment can be provided by simply moving the frame on the support or by moving the support itself.

The 3" (75 mm) plus or minus vertical adjustment can be provided by using shim pads between the drum frame and the support.

No adjustment to the position of the internal magnet element is required now because it is anchored in its initial operating position at the factory. Adjustment to the magnet element position may be needed later.

This is covered in the *Operation and Adjustments* section. Figures 2A & 2B outline the two drum frame supporting arrangements that have just been described.




FIGURE 2A. OVERHEAD SUPPORT




FIGURE 2B. UNDERNEATH SUPPORT

Feed to the Drum

The quality of separation for this drum (as is true for any magnetic separator) is determined primarily by characteristics of the feed. The feed should be uniform, level, and surges must be minimized. The size of pieces in the feed stream must be within the specifications which were the basis for the selection of the size and type drum supplied on this order.

The drum on this order, and the feed to it, are illustrated on the supplied outline drawing. This feed arrangement is one of the four arrangements that are illustrated below.

Feed to magnetic drums can be introduced in any of the three ways shown:

- Feed to the bottom of the drum as shown in Figure 3 for a double drum installation or as shown in Figure 4 for a single drum installation.
- Feed to the top of the drum as shown in Figure 5.
- Feed to the side of the drum as shown in Figure 6.

Style 1 - Double Drum

For the cleanest possible recovered metal without secondary shredding or air classification, a two drum installation as shown in Figure 3 is recommended.




FIGURE 3

Style 2 - Suspended Drum (Over the Top)

This installation, with the drum suspended at the discharge end of the conveyor, utilizes the trajectory of the discharged shredded waste to help separate loose non-magnetics and recover the ferrous materials. Feed to the separator can be either by belt conveyor, oscillating conveyor or chute.




FIGURE 4

Style 3 - Top Feed

This type of installation is recommended only for nonsticky products and large iron. It can be used to remove large liberated ferrous pieces from shredded or unshredded product.




FIGURE 5

Style 4 - Side Feed

This type of installation is typically used in foundries to remove large, heavy sprues, gates and risers from shakeout sand. The iron jumps to the magnet and is pushed/pulled over the top discharging on a ferrous take-away conveyor.




FIGURE 6

Style 5 - Under Feed

This type of installation can only be used with the P-Rex permanent drum. The underfed installation provides for maximum cleaning of product. As the product passes under the drum, multiple agitations allow for debris to fall directly away from product and not back into the line of feed like typical "over the top" installations.




FIGURE 7

See the outline drawing for the distance from the feed-conveyor or pan feeder to the drum surface.

Install the drum and feed equipment with this distance between the two. Later adjustments may have to be made to this distance. Making any changes is covered in the *Operation and Adjustments* section of this manual.

Any framework, structure, chutes, splitters, hoppers, shrouds, piping, etc. that is within 54" (1372 mm) of the 60" (1524 mm) diameter drum surface or within 48" (1219 mm) of the 36" (914 mm), 42" (1067 mm), or 48" (1219 mm) diameter drum surface must be nonmagnetic. This criterion applies within the arc that corresponds to the magnet element inside the drum.

The feed conveyor head pulley and the conveyor's belt support idlers or belt slider plate must also be non-magnetic. For the construction of the conveyor frame itself, the main conveyor side members can be steel because they are normally as far apart as the internal magnet element, but any cross supports between these side members that are within the limiting arc must be nonmagnetic. Any side shields or guards should be non-magnetic to minimize material buildup.



Operation and Adjustment

With the drum installed and supported per the *Installation* section of this manual, the drum is now ready to accept a stream of mixed ferrous and nonferrous material for separation into two streams.

Run a batch of the mixed material, at the production rate, through the system with all settings as shown on the supplied outline drawing. Observe the separation at the pick up point, then examine the two final products.

If a good split of ferrous and nonferrous material is made, no adjustments are called for. But if ferrous material is missed and ends up in the nonferrous stream, some adjustments should be made.

These adjustments are available:

1. Distance of feed stream from shell surface at pickup point.
2. Speed and depth of feed stream.
3. Rotational speed of drum.
4. Position of the magnetic element inside the drum.

The first two listed adjustments normally need not be used if all settings are per the outline drawing and if the feed is the same as that for which the drum size and type were selected. Be aware of possible jams and resulting damage in the pick up area between the drum shell and feed stream if the gap between these two is decreased.

The speed of the field stream is very important, this speed must not deliver more ferrous material to the drum than it can efficiently carry away. Loss of ferrous and entrapment of nonferrous in the ferrous stream are results of choke feeding at the pickup point.

The third listed adjustment is only for unforeseen problem installations. Running the drum faster or slower than specified on the outline drawing can in some cases hurt separation quality, so consider this adjustment carefully.

The fourth listed adjustment needs considerable explanation. It is the adjustment that, by itself, can improve separation the most. The position of the magnet element inside the drum controls where the pickup of ferrous material occurs, and also locates where the ferrous is released by the drum.

The observation of the test batch pickup will indicate whether the pickup point should be raised or lowered.

With the adjusting arm and turnbuckle positioned and mounted per the outline drawing there is a minimum of plus or minus 15° angular movement of the adjusting arm available. When the adjusting arm is moved through an arc, the magnetic circuit moves through the same arc.

To raise the pickup point on the shell, partially close the turnbuckle. To lower the pickup point on the shell, partially open it. But before you can adjust the turnbuckle, loosen the bolts that grip the clamp blocks on the shell about two turns. Do this on both ends of the shaft.

Any turnbuckle adjustments should be made in small increments. Seven or eight turns of the turnbuckle is a good first adjustment. Run another batch of mixed material through the system. If necessary, continue with the incremental adjustments.

After the pickup pole is where you want it, tighten the clamp block bolts.



Maintenance

Before any maintenance is performed, power should be shut off and locked out per the *Safety Notice* section of this manual.

Drum Shell and Wear Wrap

Once per shift, check the outside of the shell or the wear wrap (if furnished) for wear, punctures, cuts, or dents. Repair at once so that no dust, dirt, or moisture can get inside the drum. Serious damage can result.

When making repairs to the wear wrap or shell while either is in place on an assembled drum, revolve the drum shell so the damaged area is away from the internal magnetic element. Results can vary if repaired inside the magnetic field.

When inspecting the shell or wear wrap, check the joints between the shell ends and the drum heads. These joints must remain dust and moisture tight. Inspect the wipers along the outside of the drum shell (or wear wrap). Damage to or loosening of the wipers can result if there are surges, jams or oversize feed at the point of feed transfer to the drum. Repair the wipers if required.

After some running and application history the time schedule for the above inspections may be stretched out if previous inspections have shown little or negligible wear. But if there is heavy feed, large oversize pieces in the feed or for foundry applications, maintain the frequent inspection schedule given.

To remove the shell in order to make major repairs or to install a new shell, follow this sequence:

Step 1

Remove the large plate sprocket that is bolted to the drum head, so the drum head will be able to be pulled off the shaft later.

The adjusting arm holds the magnet element up. Loosen the two clamp blocks and restrain the adjusting arm with cable or chain. Disconnect the turnbuckle from the adjusting arm and slowly lower the magnet element into the gravity position by allowing the adjusting arm to move with it.



CAUTION

Do not allow the magnet element to fall into the “free” position uncontrolled.

When the magnet element is down in gravity position, the adjusting arm can be removed. Now the top half of the two clamp blocks can be removed. Prepare supports to receive the drum as shown in Figure 8.

Lift the drum as described in the *Installation* section of this manual and move it to the supports. Figure 8 shows the drum set on the supports.



Maintenance (cont.)

Step 2

Position supports as shown in Figure 8 under the two shell flanges. These supports will keep the drum shell in the horizontal and vertical position that must be maintained.

Unbolt the drum heads from the shell end flanges. Drive out the dowels between the head and shell end flanges. Remove all locking screws in the bearing collar that lock the bearings to the shaft.

Pull the heads away from the shell and all the way out to the shaft supports. This is illustrated in Figure 9.

Step 3

Look inside the drum shell and note that the magnet element is spaced away from the inner surface of the drum shell. We want to maintain this space while removing the magnet element from the shell and when putting the magnet element back into the repaired or new shell.

To maintain this space, slide some rigid spacers between the magnet element and the shell inner surface on both ends of the drum.

Now attach cables or chains around the shaft ends preferably using two cranes. If two cranes are not available, use a spreader beam so the lifts are vertical and support the element in its exact vertical position. Figure 9 illustrates this. With the element supported, remove the shaft supports at the ends of the shaft and pull the 2 drum heads off the shaft.

Step 4

Using a large pipe extension over one end of the shaft as shown in Figure 10, remove the element from inside the shell slowly and cautiously. Be sure no bumping or scraping of the element occurs during this move.

After the magnet element is removed, set the shaft ends on supports so the magnet element itself is not supporting its own weight.

After the shell is repaired or replaced, follow the above procedures in reverse to reinstall the magnet element. Be sure to remove all the internal spacers that were used.

**⚠ EXERCISE EXTREME CAUTION:
STRONG MAGNET!
SEE WARNING ON INSIDE COVER.**




FIGURE 8




FIGURE 9




FIGURE 10



Maintenance (cont.)

Drum Bearings

For lubrication guidelines, see Table 2 and refer to the Rexnord lubrication sheet in the *Additional Material* section.

The two drum bearings (one at each end of the drum) are lubricated through the 2 fittings, one at each drum hub.

Measure the drum shaft diameter and locate that diameter in the Heavy Duty Series 5000 column of the lube sheet. Read across to the right to locate the amount of grease required. Locate also the recommended interval between lubrications.

If bearing replacement is called for, see the drawing in the rear of this manual that illustrates this operation.

Chain and Sprockets

The following data applies when assembled drive has been furnished with the drum and when the drive has been furnished and installed by the user. If a manual brush on lubrication is used, it should be applied once a shift. SAE 30 oil will apply for installations at 40° to 100°F (4.4° to 37.8°C). For higher ambient temperatures use SAE 40 oil. If an oil reservoir outside the guard is used for drip lubrication, monitor the oil level. Whenever the guard is opened, check for chain and sprocket wear and clean any accumulated dirt from all surfaces including the inside of the guard. If drip lubrication is used, open the guard at least weekly.

To perform any of the maintenance described, it will be necessary to raise or remove any enclosure if one has been provided.

Repeat! See the *Safety Notice* section of this manual before any maintenance is performed.

TABLE 2: BEARING LUBRICATION (Based on 40-Hour Week)

SHAFT SIZE (INCHES)			SIZE CODE	GREASE REQUIRED, OZ.		RECOMMENDED NUMBER OF MONTHS BETWEEN RELUBRICATION					
NORMAL DUTY SERIES 2000	HEAVY DUTY SERIES 5000	ADAPTER SERIES 9000		TO LUBRICATE REBUILT UNITS	TO RELUBRICATE UNITS	RPM					
						100	300	500	1000	1750	3000
3/4 - 1 1 1/8 - 1 1/4 1 7/16 - 1 1/2	- - 1 7/16	- - -	2 THRU 4	0.4 0.5 0.6	0.1 0.1 0.1	12	8	5	2	1	1/2
1 11/16 - 1 3/4 1 15/16 - 2 2 3/16 - 2 1/4 2 3/8 - 2 1/2 2 11/16 - 3	1 1/2 - 1 11/16 1 15/16 2 - 2 3/16 2 7/16 2 1/2 - 2 15/16	- - 1 15/16 - 2 2 3/16 2 7/16 - 2 1/2	5 THRU 9	0.8 0.9 1.1 1.5 2.8	0.2 0.2 0.2 0.3 0.5	8	5	3	1	1/2	-
3 3/16 - 3 1/2 3 11/16 - 4 -	3 3/16 - 3 7/16 3 11/16 - 4 4 3/16 - 4 7/16	2 11/16 - 2 15/16 3 3/16 - 3 7/16 3 11/16 - 4	10 THRU 12	3.7 6.9 11.0	0.6 1.1 1.5	6	4	2	1	1/2	-
- - - -	4 15/16 - 5 5 7/16 5 15/16 - 6 6 15/16 - 7	4 3/16 - 4 7/16 4 15/16 - 5 5 7/16 5 15/16 - 6 7/16	13 THRU 16	14.3 22.1 25.3 33.0	2.5 4.0 4.5 6.0	4	2	1	1/2	-	-



Troubleshooting

Problem:

Drum will not pick up ferrous material.

Cause:

Drum is not installed at proper pick up distance or pick up pole is not in best position. See outline drawing and *Operation and Adjustments* section. Make adjustments as needed. Is the tip of the feeder pan steel? Is the conveyor head pulley steel? Are other chutes or shrouds in the magnet area steel?

Solution:

Check these nearby items with a steel probe to see if they are acting as a magnet themselves and attracting iron or bleeding-off some of the drum's attracting field. Replace with nonmagnetic material.

Missed parts may not really be ferrous. Check missed parts with a small permanent magnet to confirm they are magnetic and not a composite of ferrous and non-ferrous components.

Problem:

Drum won't rotate because motor protection kicks in and prevents motor rotation.

Cause:

Check whether the drum shell has been dented enough so the shell rubs against or jams against the stationary internal magnet element, causing the motor to overload. Is motor protection sized correctly?

Solution:

Remove the drive chain and try to revolve the drum. (Mechanical assistance will be needed for large drums).

If there is internal interference, the solution may require the shell to be removed and repaired. This should be done under the supervision of a factory trained technician. However, if you can locate a defined dent or depression causing this interference, you may be able to make a fix without removing the shell. First rotate the shell until the depressed area is as far away from the internal magnet element as possible. Repair the dent with the drum shell in place. Don't allow dirt or other contaminate to enter the drum during the repair. Replace with correct heater size if necessary.

Problem:

Drum won't rotate even though there's no internal interference.

Cause:

Is zero speed switch faulty or installed incorrectly?


Solution:

Replace or correct wiring. Check all wiring. Has chain broken or come off driven sprocket?

Repair and maintain good chain tension.



Bearing Removal



To Remove Bearing:

The drive end of the drum is shown, but the sequence described to remove the bearing will apply to both ends.

Whether the bearing is to be replaced on one or both ends of the drum, disconnect the wiring, the drive chain, and the adjusting arm on the far end of the shaft. When disconnecting the adjusting arm, control it so that the magnet element inside the drum moves slowly to its gravity position. It will be necessary to loosen the bolts holding the halves of the shaft clamp blocks to the shaft and attached magnetic element can rotate through a short arc (about 40°).

1. Remove top halves of the (2) shaft clamp blocks. Lift the drum (see manual) and set it on (2) prepared supports shown as 'B'.
2. Depending on which end is to be worked on, remove the adjusting arm or sprocket.
3. Put rigid supports in place at 'A', both ends.
4. Remove the split sprocket. Back off the (3) set screws 1/2" to 3/4".
5. The bearing O.D. and the hub I.D. were coated with an anti-seizing film at assembly and possible moisture and dirt entry points were sealed with silastic. The fit at bearing O.D. and hub is .002 to .006 loose.



Additional Material

The listed drawings and other data are available. They have been prepared and selected for the specific equipment.

1. Outline drawing of the DRUM or DRUM/FRAME/DRIVE assembly.
2. Bearing placement drawing with illustrations and step by step instructions for removing and replacing the bearing.
3. RECOMMENDED SPARE PARTS LIST drawing.
4. IOM data for DRIVE MOTOR, if supplied.
5. IOM data for ZERO SPEED SWITCH, if supplied.

Note: Some safety warning labels or guarding may have been removed before photographing this equipment.
Eriez and Eriez Magnetics are registered trademarks of Eriez Manufacturing Co, Erie, PA

©2013 Eriez Magnetics All Rights Reserved



World Authority in Separation Technologies

Headquarters: 2200 Asbury Road, Erie, PA 16506-1402 U.S.A.

Telephone: 814/835-6000 • 800/345-4946 • Fax: 814/838-4960 • International Fax: 814/833-3348

Web Site: <http://www.eriez.com> e-mail: eriez@eriez.com

Manufacturing Facilities: AUSTRALIA • BRAZIL • CANADA • CHINA • INDIA • JAPAN • MEXICO • SOUTH AFRICA • UNITED KINGDOM • UNITED STATES