

Installation, Operation and Maintenance Instructions



VIBRATORY FEEDER MODELS – 46C, 56C & 66C

ERIEZ MAGNETICS HEADQUARTERS: 2200 ASBURY ROAD, ERIE, PA 16506-1402 U.S.A.
WORLD AUTHORITY IN SEPARATION TECHNOLOGIES

Introduction

This manual details the proper steps for installing, operating and maintaining the Eriez Vibratory Feeder.

Careful attention to these requirements will assure the most efficient and dependable performance of this equipment.

If there are any questions or comments about the manual, please call Eriez at 814/835-6000 for Vibratory Feeder assistance.



CAUTION

Safety labels must be affixed to this product. Should the safety label(s) be damaged, dislodged or removed, contact Eriez for replacement.

Table of Contents

VIBRATORY FEEDER - MODELS 46C, 56C & 66C

| | |
|---|----|
| USER TECHNICAL SAFETY INFORMATION..... | 4 |
| INSTALLATION | 5 |
| Mounting..... | 5 |
| Electrical Connections | 5 |
| OPERATION AND MAINTENANCE | 6 |
| Tuning Guide | 6 |
| How To Measure Displacement..... | 6 |
| Tuning for Non-Standard Trays | 7 |
| Tuning for Different Conditions of Tray Loading | 7 |
| REPAIRS | 8 |
| Coil Replacement | 8 |
| Spring Change or Replacement | 9 |
| Armature Replacement..... | 10 |
| The Hi-Vi Magnetic Drive Circuit..... | 11 |
| TROUBLESHOOTING | 12 |
| DECLARATION OF CONFORMITY | 14 |

User Technical Safety Information

The following instructions are provided for the personal safety of operators and also for the protection of the described product and connected equipment. Also refer to the IOM for the CE approved feeder control for additional safety information

- Eriez has applied due diligence to ensure that our drives, feeders and feeder systems are CE compliant. When part of the feeder system is purchased from Eriez, the customer must select components that make the feeder system (drive(s) + tray + control) CE compliant.
- The drivers, feeders and controls are NOT approved for operation in hazardous locations.
- Equipment is to be assembled and installed according to the IOM and local electrical/safety codes by qualified personnel.
- Isolate the mains before installing, dismantling or repairing the equipment, as well as for fuse changes or post installation modifications.
- Do not operate the equipment if the feeder power cable or control power cable is damaged.
- All electrical connections must be covered.
- All earth (ground) connections must be checked for correct function after installation.
- Equipment is to be operated by technically qualified personnel.
- Personnel are to maintain a safe distance from the equipment during operation. Do NOT stand, sit or lay on the vibratory feeders during operation.
- Safety devices/relays must be installed by the end user to ensure that the feeder does not start prematurely if power to the control is interrupted and restored.
- The end user of the feeder must determine if hearing protection is required for their feeder application.
- The end user bears responsibility to specify an enclosed tray for dusty product where a potential health hazard is present.
- Eriez drivers produce a weak magnetic field during operation. The end user bears the responsibility to assess if this magnetic field will affect employees with medical devices, and provide adequate warning regarding this potential risk.
- The surface of the driver electrical assembly may exceed 149°F depending upon tuning requirements. Do not contact this surface until sufficient time (30 minutes) is provided after shutdown for this surface to cool.
- Certain products (plastics, for example) can create a static charge as it is introduced, conveyed and removed from vibratory feeder trays. The end user must assess if this static charge presents a health or a safety hazard. Eriez can supply trays with Earth grounding devices upon request.



Installation

Mounting

This Hi-Vi model should be mounted on a flat surface, fastened with bolts of proper size. Use lock washers under the bolt heads.



FIGURE 1

Electrical Connections

NOTE: The Eriez Vibratory Feeder is designed to be operated from an AC source. It cannot be operated from a DC source.

All wiring should conform to all applicable electrical codes.

1. Check the specifications of the power line to be certain that they are the same as those shown on the nameplate.
2. Connect the black and white wires in the Feeder power cord to the power source or to the proper terminals in the control box.
3. Connect the green wire to the ground or to the lug provided in the control box.
4. If using a control box, make all connections as indicated on the control wiring diagram.
5. Connect the ground lug in the control box to a good earth ground (a cold water line is excellent).
6. On multiple drive feeders (two or more drives on one tray) all drives should be wired electrically in phase and in parallel. The black wires from each power cord should be connected together and the white wires connected together. The black wires should be connected to the line side of the input voltage and the white wires should be connected to the neutral side.

YOU ARE NOW READY TO START YOUR VIBRATORY FEEDER.

Operation & Maintenance

Do not operate the unit with associated equipment touching any part of the unit.

To start the feeder after all connections have been made, apply power to the line connected to the feeder. If a controller is used, operate the switch on the controller and adjust the output voltage to maximum by rotating the control knob to the full clockwise position. Ordinarily (at ordinary room temperatures) the unit will take about two minutes to reach full steady-state displacement.

After full steady-state displacement has been attained, use the controller to adjust the unit to the desired feed rate.

No routine maintenance or lubrication is required, except that any accumulation of foreign matter should be periodically removed from between the tray-tiebar assembly and the body, and from between the body and the mounting surface, to prevent restriction of movement of the vibratory elements.

IMPORTANT NOTE:

Special Trays and Attachments

Eriez engineering service should always be consulted before undertaking the design or construction of special trays. Standard or special trays as furnished by Eriez should not be modified or attachments made without first contacting Eriez. To do so will void the warranty. (See Standard Tray Specifications.)

Tuning Guide

General Information

The tuning means is provided solely for the purpose of mechanically tuning the unit, with its tray, to the desired vibratory displacement at full voltage. When a unit is furnished complete with tray, it is properly tuned to the tray at the factory. Such tuning is naturally somewhat different for trays of different size or weight.

Tuning is accomplished by changing the stiffness of the tuning spring stacks of the feeder (see Figure 2). Variations in stiffness are obtained by changing the number of springs in the stacks and/or by changing the thickness of fiberglass springs.






FIGURE 2

In normal operation at full voltage, the total displacement for standard size trays, measured at the back of the tray, is .055" to .060" (1.4 mm to 1.5 mm). For trays substantially larger than standard this normal displacement range should be reduced. Refer to the serial number plate on your feeder for the amplitude to which your unit was tuned.

How to Measure Displacement

Position an Eriez displacement sticker on the outer side of the tray, near the rear of the tray and at an angle of 25° from vertical (see Figure 3).



Stroke gauge under vibration (shown at .060" displacement)

FIGURE 3



Operation & Maintenance (cont.)

With unit operating at full voltage and tray empty, observe where the fine gray lines on the displacement sticker meet. This point will be higher or lower as the displacement changes. Opposite the point where they meet, read amount of displacement.

The following general rules, which apply only to the feeder operating ideally on the "normal" side of its "tuning curve," should be borne in mind when making tuning adjustments to increase or decrease the displacement:

1. To DECREASE the tray displacement, INCREASE the stiffness of the tuning springs.
2. To INCREASE the tray displacement, DECREASE the stiffness of the tuning springs.

If decreasing or increasing the tuning spring stiffness has an opposite effect, it means that the spring stiffness is not great enough, and that the unit is operating on the "opposite" side of its tuning curve. The spring stiffness should be increased until the behavior is in accordance with rules 1 and 2. The unit can then be properly tuned to the desired displacement.

As a guide to the stiffness of individual tuning springs, each spring is marked with a code number- example, 5-27. The first number (5) is the number of fiberglass plies in the spring. The following number (27) indicates the relative stiffness of the spring; the higher this number the stiffer the spring.

The total stiffness of the tuning spring stack is the sum of the relative stiffness numbers. By various combinations of different ply springs having different relative stiffnesses, practically any desired total stiffness can be obtained.

Tuning For Non-Standard Trays

(Note: See "Special Trays and Attachments")

If it is necessary to tune the unit to an off-size or non-standard tray, follow this procedure:

1. Attach the tray, making sure that all lockwashers are in place and the fasteners are tight.
2. Energize the unit at the nameplate voltage and frequency.
3. (a) During tuning, if a hammering or striking noise appears during warm-ups or if such a noise occurs when the unit is turned off and on quickly, the displacement is well in excess of normal. Whether striking or not, if the displacement exceeds the normal range for that particular size of tray (see Tuning Guide-General Information), it must be reduced by substituting a tuning spring of greater stiffness, or by changing one or more springs, until approximately normal displacement is attained at full voltage. Then use the controller for fine or variable control of displacement and feed rate.
(b) If the displacement at full voltage after warmup is below the nominal range for that particular size tray, and greater displacement is desired, decrease the tuning spring stiffness by substituting leaves of lesser stiffness or by subtracting more leaves.

Tuning For Different Conditions of Tray Loading

Units with Eriez-built trays are factory tuned for normal displacement (approximately .055" to .060" [1.4 mm to 1.5 mm]) with light loading (light head load, light materials, limited depth of flow of heavier materials). Ordinarily this tuning will not need to be changed. In no case should the unit be permitted to deflect more than .060" (1.5 mm) without load.

CAUTION: A small amount of striking during tuning is permissible, but must not be allowed during regular operation since damage to the feeder can result.

Repairs

Coil Replacement

Refer to Figs. 4, 5, 6 & 7.

The following procedure should be followed in removing and replacing the electrical assembly, which includes the coil:

1. Remove both nameplates and insert the gap spacers (furnished with the unit) between the E-frame center leg and the two armature pole pieces (see Figure 4 & 5).




FIGURE 4




FIGURE 5

2. Remove, in order, the bolts securing the upper end of the rear tuning spring stack to the tiebar. Lift the tray-tiebar-lever assembly away from the body housing (see Figure 6).




FIGURE 6

3. Remove the bolts securing the electrical assembly to the body housing and lift the assembly out of the body housing (see Figure 7).




FIGURE 7

4. If the coil is defective, the entire E-frame assembly including the coil must be replaced (order from Eriez parts list).

5. In reassembling the unit, first center the armature at the bottom of the body cavity; then insert the E-frame into the body cavity, making sure that the center leg enters the space between the armature pole pieces. Insert the bolts securing the electrical assembly and fasten only finger tight.
6. Place the tray-tiebar-lever assembly into its original position and replace, in order, the bolts securing (a) the lower end of the tiebar to the spring bar, and (b) the upper end of the rear tuning spring stack to the tiebar. Make sure that all tuning spring spacers are in place and that all bolts are tight.
7. Loosen the electrical assembly bolts slightly and roughly center the E-frame center leg between the pole pieces. Insert the spacer between the E-frame center leg and the pole pieces and adjust the electrical assembly forward or backward until the spacer moves freely in the gaps. Tighten the electrical assembly plate and replace the nameplates.

Spring Change Or Replacement

Refer to Figs. 8 & 9.

Although the non-metallic springs used in the Feeder have outstanding life characteristics, failure may eventually occur, especially if the displacement is greater than normal. The symptoms of such failure will be:

1. Erratic behavior of the unit, or
2. Greatly reduced displacement.

If spring failure is suspected, the rear tuning spring stack should be removed after first inserting the two gap spacers between the center leg of the E-frame and the two pole pieces (Figure 8). The purpose of this is to hold the tiebar or tray-tiebar assembly in position while the tuning springs are removed.




FIGURE 8

If after inspection of the rear tuning spring stack, the front stack is suspected, use the ARMATURE REPLACEMENT procedure as a guide for re-assembly with **special attention to the washer shaped spacers between the spring bar and armature.**

Carefully examine each tuning spring for signs of delamination or breakage, especially in the area next to the spring spacer. A failed spring can be recognized by the appearance of the spring surface. If this surface is discolored or has a patchy whitish appearance, perhaps accompanied by surface burying or other irregularity, the spring is defective and should be replaced with a new spring ordered from the parts list.

CAUTION: Make sure that all of the fasteners in the assembly are tight at all times. Periodic checks for tightness should be made to insure against possible malfunction or damage due to loose parts.

Note: The front spring stack always remains the same on the feeder and should not be altered when returning the unit. The following applies:

| MODEL | STANDARD REAR SPRING COMBINATION | |
|-------|----------------------------------|--------------------|
| | 50 Hz | 60 Hz |
| 46 | 3-17 ply, 1-5 ply | 2-19 ply, 3-15 ply |
| 56 | 3-15 ply, 2-13 ply | 4-19 ply |
| 66 | 2-19 ply, 2-17 ply | 4-19 ply, 1-15 ply |

| MODEL | STANDARD FRONT SPRING COMBINATION | |
|-------|-----------------------------------|------------|
| | 50 Hz | 60 Hz |
| 46 | (3) 13 ply | (3) 15 ply |
| 56 | (4) 17 ply | (4) 17 ply |
| 66 | (4) 17 ply | (4) 19 ply |

Repairs (cont.)

Feeder Drive Only (Less Tray Supplied)

If a feeder is shipped without a tray, the standard rear spring combination for the feeder is listed below.

These feeders will need to be tuned to the tray.

Refer to TUNING FOR NON-STANDARD TRAY section

Note: The front spring stack always remains the same on the feeder and should not be altered when retuning the unit. The following applies:

| FRONT SPRING COMBINATIONS | | STANDARD REAR SPRING COMBINATIONS | |
|---------------------------|----------|-----------------------------------|---------|
| 50 Hz | 60 Hz | 50 Hz | 60 Hz |
| 1-9 ply | 1-13 ply | 1-11 ply | 2-9 ply |
| | | 1-9 ply | 1-7 ply |
| | | 1-7 ply | 1-7 ply |
| | | 1-9 ply | 1-5 ply |

TABLE 1. TORQUE CHART
46 & 56 Series

| Part | Bolt Size | Torque | |
|------------------------|-----------|--------|--------|
| | | m-kgs | ft-lbs |
| Rear Spring Bolts | M14-2 | 11.8 | 85.3 |
| Torsion Spring Bolts | M12-1.75 | 11.8 | 85.3 |
| Front Tie Bar Bolts | M14-2 | 11.8 | 85.3 |
| Front Spring Bolt | M14-2 | 11.8 | 85.3 |
| Electrical Ass'y Bolts | M8-1.25 | 2.4 | 17.4 |
| Tray Bolts | M8-1.25 | 1.5 | 10.8 |

66 Series

| Part | Bolt Size | Torque | |
|------------------------|-----------|--------|--------|
| | | m-kgs | ft-lbs |
| Rear Spring Bolts | M16-2 | 15.2 | 109.9 |
| Torsion Spring Bolts | M12-1.75 | 11.8 | 85.3 |
| Front Tie Bar Bolts | M16-2 | 15.2 | 109.9 |
| Front Spring Bolt | M16-2 | 11.8 | 109.9 |
| Electrical Ass'y Bolts | M8-1.25 | 2.4 | 17.4 |
| Tray Nut | M12-1.75 | 7 | 50.6 |

Armature Replacement

Refer to Figs. 4, 5, 6 & 7.

Prolonged striking may damage the armature to an extent that it will have to be replaced. If this should become necessary, order a new armature from the parts list and begin by following the same instructions as for coil replacement.

1. Continue by removing in order the bolts securing the elastomer diaphragm clamp to the body housing.
2. Loosen slightly but do not remove the upper end of the front tuning spring stacks to the spring bar and the spring bar to the armature.

3. Loosen the bolts securing the lower end of the spring stacks to the body housing leaving 1-2 threads in the body housing. Carefully slide the spring stack and the armature assembly back to the bolt heads and remove the bolts from the body housing. (Do not remove bolts from the spring stacks).
4. Remove the armature and spring stack assembly by grasping the spring stacks and sliding it through the opening in the body housing. NOTE: use a downward pressure when removing this assembly to keep the magnetic poles of the armature from coming in contact with the body housing when going through the opening.
5. Stand the armature and spring stack assembly on a non-magnetic surface (I.E. wooden table) as shown in Figure 9. NOTE: Keep armature away from any steel parts and surfaces.
6. Loosen the bolts securing the spring stacks to the armature and remove the spring stacks with the bolts intact. Retain the washer shaped spacers located between spring bar and armature. Note the position of the elastomer diaphragm when reassembling.
7. Center washer shaped spacers on tapped holes of the armature. (Hint: using an instant adhesive will keep the washers and elastomer diaphragm in position while reassembling.) Position elastomer diaphragm on the armature as shown in Figure 10. Reverse the above procedure to reassemble the unit.



FIGURE 9




FIGURE 10

Repairs (cont.)

8. Insert armature and diaphragm assembly through opening in front of base casting as shown in Figure 11.




FIGURE 11

9. Final assembly as follows:

- Check that the electrical E-frame and armature assemblies are positioned with gap bars provided. (Hand tight).
- Attach the tie bar to the rear of the body housing using the existing rear tuning spring stack, and bolts. (Tighten).
- Connect the tie bar to the front of the spring bar. (Torque - see Table 1).
- Check clearances. (Gap bars).
- Tighten front spring stack. (Torque - see Table 1).
- Tighten rear spring stack. (Torque - see Table 1).
- Tighten electrical E-frame assembly. (Torque - see Table 1).
- Check all fasteners. (Check torque - see Table 1).

The Hi-Vi Magnetic Drive Circuit

Old-style electromagnetic equipment has an inefficient attract-release type operation, where a mass mounted on springs is attracted by a DC electromagnet and returned to its original position solely by the springs. The new Hi-Vi method incorporates a lifetime permanent ceramic magnet and is operated directly from an alternating current line.

In the Hi-Vi method, the spring-mounted mass is alternately both attracted and repelled by an AC electromagnet assisted by the springs.

Intermeshing a fixed polarity permanent magnet with an alternating polarity AC electromagnet eliminates the rectifier since you would have an alternating attracting and repelling force as the polarity of the electromagnet alternated.




FIGURE 12

It will be noted that the pole pieces of the permanent magnet are intermeshed in the air gaps of an electromagnet. The polarity of the permanent magnet is fixed; the polarity of the electromagnet alternates at the line frequency. We have shown the polarity of the electromagnet as it would exist on one side of the sine wave. Note that both poles of the permanent magnet are being attracted toward the unlike electromagnet poles. They are also being repelled in the same direction by the like electromagnet poles. This results in four forces accumulating to drive the armature in the same direction. It also results in closing the magnetic circuit through the electromagnet providing a magnetizing effect on the permanent magnet on each side of the sine wave. The demagnetizing force is very minor for the attracting force and the magnetic lines of flux would much prefer to be attracted than repelled. This always tends to place the permanent magnet in a magnetizing circuit regardless of where the AC current is on the sine wave. As the polarity of the electromagnet changes, all of the forces are reversed and the permanent magnet armature is driven in the opposite direction.

CAUTION: Operation from portable engine driven power plants.

Varying and unstable line frequency has a diverse effect on vibratory feeders because they are tuned mechanical devices, designed around either 50 or 60 cycle operating frequency. Shifts in the operating point due to changes in frequency (+ or -1 cycle) cause higher than normal spring stress, striking and high line currents which can cause drive and tray failure. When operating from portable engine-driven power plants, be certain that the engine is up to speed and all other loads are started and at running speed before starting the electromagnet feeder.

The feeder should always be stopped first when the engine-driven power plant is shut down.

Troubleshooting

Troubleshooting

TABLE 2. SERVICE CHART

| NATURE OF PROBLEM | | Misapplication | Tampering or Changing of Base or Tray | Loose Spring Clamp or Tray Mounting Bolts | Coil Failure | Control Failure | Incorrect Voltage | Spring Failure | Foreign Material Between Tray & Reaction Mass | Incorrect Tuning | Poor or Broken Weld on Tray | Incorrect Factory Adjustment | Sympathetic Vibration in Other Equipment | In Contact with Other Equipment | Line Voltage or Hz Variation | Blown Fuse or Circuit Breaker | Other Electrical Connections | Shockmount Deterioration | Corrosive or Abrasive Material | Product Variation or Product Sticking to Tray |
|--|------------------------------|----------------|---------------------------------------|---|--------------|-----------------|-------------------|----------------|---|------------------|-----------------------------|------------------------------|--|---------------------------------|------------------------------|-------------------------------|------------------------------|--------------------------|--------------------------------|---|
| | | 1 | 2 | 3 | | 5 | 6 | 7 | 8 | 9 | | 11 | 12 | 13 | 14 | | 16 | | | 19 |
| Initial Installation | Reduced or Low Output | 1 | 2 | 3 | | 5 | 6 | 7 | 8 | 9 | | | 12 | 13 | 14 | | 16 | | | 19 |
| | Noisy but Output Okay | | | 3 | | | | | 8 | 9 | 10 | 11 | 12 | 13 | | | | | | 19 |
| | Noisy Certain Periods Only | | | | | | | | | | | | | 13 | 14 | | | | | 19 |
| Develop After Satisfactory Initial Operation | Completely Inoperative | | 2 | | 4 | 5 | | 7 | | 9 | | | | 13 | | 15 | 16 | | | |
| | Operating But Reduced Output | | 2 | 3 | | 5 | 6 | 7 | 8 | 9 | 10 | | 12 | 13 | 14 | | 16 | | | 19 |
| | Output Okay Too Much Noise | | | | | | | 7 | 8 | 9 | 10 | | | 13 | 14 | | | | | 19 |
| | Gradual Fading | | 2 | | | 5 | | 7 | 8 | | 10 | | | | | | 16 | | | 19 |
| | Excessive Tray Wear | | | | | | | | | | | | | | | | | | 18 | |
| | Turbulent Flow | | | | | | | | | 9 | 10 | | | | 14 | | | 17 | | |
| | Inconsistent Output | | 2 | 3 | | 5 | 6 | 7 | 8 | 9 | 10 | | 12 | 13 | 14 | | 16 | | | 19 |



Troubleshooting (*cont.*)

Refer To Table 2. Service Chart

- 1. Misapplication**
Feeder too small. Product difficult or impossible to handle. Impossible temperatures or atmospheres. Impossible dimensional requirements. Feeding requirements too precise or excessive. Consult Eriez.
- 2. Tampering or Changing of Base or Tray**
Improper disassembly, extensions, covers, weights, screens or other modifications or attachments may have affected performance. Reassemble in accordance with printed instructions or consult Eriez.
- 3. Loose Spring Clamp or Tray Mounting Bolts**
Tighten all bolts.
- 4. Coil Failure**
Replace coil or coil and “E” frame assembly. Order from Eriez parts lists. Follow maintenance instructions carefully.
- 5. Control Failure (if applicable)**
Check control for proper wiring and function. Inspect for defective components.
- 6. Incorrect voltage**
- 7. Spring Failure**
See maintenance instructions. Disassemble for examination. Tuning spring failure will also show up as white areas. Order new parts from factory and replace per instructions.
- 8. Foreign Material**
Examine and remove foreign material.
- 9. Incorrect Tuning**
See maintenance instructions. To increase displacement and output, use fewer or thinner tuning springs. To decrease displacement and eliminate striking, use more or thicker tuning springs.
- 10. Poor or Broken Weld on Tray**
Check and correct.
- 11. Incorrect Factory Adjustment**
See maintenance instructions (Gap adjustments.)
- 12. Sympathetic Vibration in Other Equipment**
Check and correct.
- 13. Contact with Other Equipment**
Check and correct.
- 14. Line Voltage or Hz Variation**
Check and install voltage regulator if necessary. Check and install Hz regulator.
- 15. Blown Fuse or Circuit Breaker**
Check for short circuits and correct.
- 16. Other Electrical Connections**
Check all connections and correct.
- 17. Shockmount Deterioration**
Check and correct.
- 18. Corrosive or Abrasive Material**
May require special tray. Consult Eriez.
- 19. Product Variation or Product Sticking to Tray**
If product density, moisture content or other characteristics vary, customer should take own corrective measures, such as cleaning tray surface periodically.

Declaration of Conformity

Eriez Manufacturing declares that the Electromagnetic Vibratory drives conform to the following:

EN 60204-1 in accordance with the Low Voltage Directive (73/23/EEC).

Eriez Manufacturing declares that the Electromagnetic Feeders (vibratory drives with trays) conform to the following:

EN 60204-1 in accordance with the Low Voltage Directive (73/23/EEC).

EN ISO 12100-1, BS EN ISO 12100-2, and EN 1050 in accordance with the Machinery Directive (98/37/EC).

Eriez Manufacturing declares that the Electromagnetic Feeder System (vibratory drives with trays and controls) conform to the following:

EN 60204-1 in accordance with the Low Voltage Directive (73/23/EEC).

EN ISO 12100-1, BS EN ISO 12100-2, and EN 1050 in accordance with the Machinery Directive (98/37/EC).

EN 61000-6-4 and EN 61000-6-2 in accordance with the Electromagnetic Compatibility Directive (89/336/EEC).



Note: Some safety warning labels or guarding may have been removed before photographing this equipment.

Eriez and Eriez Magnetics are registered trademarks of Eriez Manufacturing Co, Erie, PA

©2013 Eriez Magnetics

All Rights Reserved



World Authority in Separation Technologies

Headquarters: 2200 Asbury Road, Erie, PA 16506-1402 U.S.A.

Telephone: 814/835-6000 • 800/345-4946 • Fax: 814/838-4960 • International Fax: 814/833-3348

Web Site: <http://www.eriez.com> e-mail: eriez@eriez.com

Manufacturing Facilities: AUSTRALIA • BRAZIL • CANADA • CHINA • INDIA • JAPAN • MEXICO • SOUTH AFRICA • UNITED KINGDOM • UNITED STATES